

www.dewesoft.com - Copyright © 2000 - 2025 Dewesoft d.o.o., all rights reserved.

Modal Test and Modal Analysis



What is Frequency Response Function - FRF

Frequency response function H(f) in the frequency domain and impulse response function h(t) in the time domain are used to describe input-output (force-response) relationships of any system, where signal a(t) and b(t) represent input and output of the physical system. The system is assumed to be linear and time-invariant. Frequency response function and impulse response function are so-called system descriptors. They are independent of the signals involved.





Image 1: Explanation of frequency response function

In the table below you can see typical frequency response function formulations:

Dynamic stiffness Force / Displacement Receptance Displacement / Force

Impedance	Force / Velocity
Mobility	Velocity / Force
Dynamic inertia	Force / Acceleration
Accelerance	Acceleration / Force

The estimation of the frequency response function depends upon the transformation of data from time to the frequency domain. For this computation, we use the <u>Fast Fourier transform (FFT)</u> algorithm which is based on a limited time history. The frequency response functions satisfy the following single and multiple input relationships:

Single Input Relationship

$X_p = H_{pq} \ F_q$

Xp is a spectrum of the output, Fp is a spectrum of the input, and Hpq is frequency response function.

Multiple Input Relationship

$$\begin{bmatrix} X_1 \\ X_2 \\ \cdot \\ \cdot \\ X_p \end{bmatrix}_{N_o \times 1} = \begin{bmatrix} H_{11} & \cdot & \cdot & \cdot & \cdot & \cdot & H_{1q} \\ H_{21} & & & \cdot & \cdot \\ \cdot & \cdot & & \cdot & \cdot & \cdot \\ H_{p1} & \cdot & \cdot & \cdot & \cdot & \cdot & H_{pq} \end{bmatrix}_{N_o \times N_i} \begin{bmatrix} F_1 \\ F_2 \\ \cdot \\ \cdot \\ F_q \end{bmatrix}_{N_i \times 1}$$

In the image below we can see an example of two inputs - two outputs case.





Modal Test and Modal Analysis in Dewesoftx Software

<u>Modal test</u> and analysis are used to determine structural modal parameters, such as modal frequencies, damping ratios, and mode shapes. The measured excitation and response (or only response) data are utilized in modal analysis, and then dynamic signal analysis and modal parameter identification are processed. Modal test and analysis techniques have been developed for more than three decades, and a lot of progress has been made. It has been widely applied to the engineering field, such as the dynamic design, manufacture and maintenance, vibration and noise reduction, vibration control, condition monitoring, fault detection, model updating, and model validation.

<u>Modal test and analysis</u> is needed in every modern construction. The measurement of system parameters, called modal parameters, are essential to predict the behavior of a structure.

These modal parameters are also needed for mathematical models. Parameters like resonance frequency, structural damping, and mode shapes are experimentally measured and calculated.

The **Dewesoft Modal Test module** is what you use when performing structural dynamic test measurements of objects. The Modal Test provides calculated FRF functions (amplitude and phase) over a certain frequency range.

The **Dewesoft Modal Analysis module** is used after the modal test data acquisition in order to estimate high quality modal models.

The Modal Analysis module uses the results from Modal Test, e.g. FRFs, to estimate modal parameters (resonance frequencies, damping ratios and mode shapes)

The Dewesoft Modal Test module also provides tools to determine modal parameters as well, but these tools only apply for simple structures, having lightly damped and well separated modes.

Dewesoft Modal Analysis is required to obtain valid modal parameters for **complex structures**, having multiple resonance frequencies being **closely spaced** or with **heavy damping**.

The Dewesoft <u>Modal test module</u> is included in the <u>Dewesoft X</u> DSA package (along with other modules e.g. <u>Order tracking</u>, <u>Torsional vibration</u>, etc.).

The Dewesoft Modal Analysis module comes as a separate license and is not included in the DSA package.

With the small, handy form factor of Dewesoft data acquisition instruments (<u>DEWE-43</u>, <u>SIRIUSi</u>), it is also a smart portable solution for technical consultants coping with failure detection.

Let's assume there is a mechanical structure to be analyzed. Where are the resonances? Which frequencies can be problematic and should be avoided? How to measure that and what about the quality of the measurement? Probably the easiest way is exciting the structure using a modal hammer (force input) and acceleration sensors for the measurement of the response (acceleration output). At first, the structure is graphically defined in the geometry editor.

Then the points for excitation and response are selected and linked to the defined geometry. The test person knocks on the test points while the software collects the data. Next to extracting phase and amplitude, it is possible to animate the structure for the frequencies of interest. The coherence acts as a measure for the quality. The modal circle display widget provides higher frequency precision and damping factors for modes on simple structures. For additional analysis and for handling complex structures you continue using the modal analysis module.

If desired the data can be exported to several file formats like the widely used UNV format.



Example of a Modal Test application.



Example of a Modal Analysis application.

LTI - Linear, Time-invariant Systems

At first, we have to assume that the methods described here apply to LTI (linear, time-invariant) systems or systems that come close to that. LTI systems, from applied mathematics which appear in a lot of technical areas, have the following characteristics:

- Linearity: the relationship between input and output is a linear map (scaled and summed functions at the input will also exist at the output but with different scaling factors)
- Time-invariant: whether an input is applied to the system now or any time later, it will be identical

Furthermore, the fundamental result in the LTI system theory is that any LTI system can be characterized entirely by a single function called the system's impulse response. The output of the system is a convolution of the input to the system with the system's impulse response.





Image 4: Linear and time-invariant system

What is Transfer Function

Transfer functions are widely used in the analysis of systems and the main types are:

- mechanical excite the structure with a modal hammer or modal shaker and measure the input force excitation together with the output responses from e.g. accelerometer sensors.
- electrical apply a voltage to the circuit on the input, measure the voltage on the output

For example, in mechanical structures, the transfer characteristics will be able to show dangerous resonances. The frequency range, where the stress of the material is too high, has to be avoided, e.g. by specifying a limited operating range. A simplified process works like this: an input signal x(t) is applied to the system and measured together with the output signal y(t). The division of response to excitation in the frequency domain basically gives the transfer function:

$$H(f) = \frac{Y(f)}{X(f)}$$

In time-domain, this is described in the following way:



Laplace transformation leads to the result in the frequency domain:



On the picture below we can see a diagram of Laplace transform, which is often interpreted as a transformation from the timedomain (inputs and outputs are functions of time) to the frequency-domain (inputs and outputs are functions of complex angular frequency), in radians per unit time. Given a simple mathematical or functional description of an input or output to a system, the Laplace transform provides an alternative functional description that often simplifies the process of analyzing the behavior of the system, or in synthesizing a new system based on a set of specifications.



Image 7: Laplace transform from the time domain to the frequency domain

How to obtain the transfer function

1. Mechanical structure

2.

- Excite the structure with modal hammer or shaker (measure force)
- Measure the response with accelerometers (acceleration)
- 3. Electrical circuit
- 4.
- Apply a voltage to the circuit on the input and measure it.
- Measure the voltage on the output of the circuit

Calculate the transfer function between the measured input and output of the system

Calculate the coherence function. A coherence value of 1 indicates that the measured response is caused totally by the measured input. If the coherence is less than one at any frequency it indicates that the measured response is not only caused be the measured input, but also be additional factors like noise sources.

Enabling and Adding Modal Test in Dewesoft X

In order to get started with modal test and analysis, you add the Modal test and (optionally) the Modal analysis modules like indicated in the picture below:



Adding Modal test and Modal Analysis modules in Dewesoft.

This training material will start with focusing on the Modal Test part, and then we will get back to the Modal Analysis part later on.

When you add the Modal test module the following setup screen appears:

MT +								Used	∨ Setup	 ✓ Rename 	\mathbf{X}
		Excitation	Response	Transfer functions	Geometry edito	r	Time mindance				_
Test method Impact Hammer Roving hammer/response		Pretrigger 1 20 samples	∽ %	Trigger level	- 1	nit level	Window Force	~	Window length 100	%	
FRF Resolution		•	Autofill.	Search	٩	Show me	ssage if excitation	exceeds 5	-		
Spectral lines v 1024 lines: 1024, df: 2,44 Hz, duration: 0),41 s	Node ID	Direction	Sign	Input	Physical quan	ntity Units				
Averaging type Linear ~											
Stop after 4 avg.											
Output channels		Signal previ	ew								
Output	Used	Display opti	ons 🔳			1	Signal prev	iew	I		1
H2 transfer functions *	Unused	Input		ents 0							+
Ordinary coherence	Used	Trigger	evel 🗧	{							+
Multiple coherence *	Unused		B								+
Power spectral density	Unused										+
Ordinary mode indicator function	Unused			-4,0		100,0	200,0 X avia (m	-)	300,0	405	,4
Intermediate Fourier transforms	Unused			1.1.1			x axis (m	s)	L . 1977		

Modal	test	setup	user	interface.
-------	------	-------	------	------------

Test methods

Depending on the application, <u>Dewesoft</u> offers three different Test methods:

- Impact Hammer the structure is excited by impacts from e.g. a modal hammer.
- Shaker the structure is excited by one or multiple modal shakers. The shaker signals can be provided be either Dewesoft AO channels or by other external sources.
- ODS operational deflection shapes, do not use external excitations, but instead the excitations coming from the structure in operation. Hereby, only output response channels are measured. ODS is used for animations of structural deflection shapes, but does not provide a modal model like obtained when using the Impact Hammer or Shaker test methods.

Impact Hammer Test, Triggered FRF

A modal test method that is relatively easy to configure is when using a modal hammer. The hammer is used for exciting the structure with a short impulse (giving a broadband frequency excitation) and one or multiple acceleration sensors are measuring the response. The hammer has a force sensor integrated and an interchangeable hammer tip that can have different stiffness. Depending of the tip used the frequency bandwidth will be between about 0.5 kHz to 3 kHz. For bigger structures, there are big hammers available with more mass to generate a distinct amplitude.



Exciting the structure with a modal hammer and measuring the response with an accelerometer



frequencies. On the other hand, with a hard tip double-hits appear more frequently.

The two pictures below show the comparison. The scopes on the top show time-domain, FFTs below show frequency domain (same scaling).



When you have set the calculation type to Impact hammer, the setup looks like the one shown below.

On the Excitation tab, specify the Node IDs where the hammer will hit and on the Response tab the response(s) being acceleration sensor(s) for all Node IDs where they will be located. In the pictures below, we have named the two analog channels Modal Hammer and Acc 1.



Defining the excitation signals.

MT +									Us	ed '	Setup	~	Rename	\mathbf{x}
				1_				1						
Measurement		Excitation Response cl	Response	Trans	fer functions	Geometry ed	itor		_	_	_	_	_	
Test method Impact Hammer		•	Autofill.		Search	۹								
Roving hammer/response		Node ID	Direction	Sign	In	put		Physical quantity	Units	G	roup			
	_	1	Z	+	Ad	c 1		Acceleration	m/s2	:	1Z+			
Resolution														
Spectral lines v 1024														
lines: 1024, df: 5,38 Hz, duration: 0,	,186 s													
Averaging type Linear ~														
Stop after 4 avg.														
Output channels		Signal previ	iew											
Output	Used	Display opti	ions 🔳					C:	-1					
H1 transfer functions	Used	Window	<u> </u>	20	2			Sign	ai previe	w				
H2 transfer functions *	Unused	🗹 Input	_	s tis	<u>n</u>									
Ordinary coherence	Used			effici		w								
Multiple coherence *	Unused		B	W CO	- 1									
Power spectral density	Unused			0 s	2°0									
Ordinary mode indicator function	Unused			2	-3,7		5	50,0	10	00,0		150,0	18	2,0
Intermediate Fourier transforms	Unused							Xa	axis (ms)					

Defining the response signals.

FRF Channel Setup inside Dewesoft Data Acquisition Software

[Video available in the online version]

Trigger parameters

Let's do a short measurement to explain all the parameters. The structure is hit once and the signals are measured.



The hammer signal (upper, blue line) shows a clean shock impact and high damping while the response (lower, red line) starts ringing and smoothly fades out.

Trigger level

The Modal test module needs a start criteria in triggered mode like when using the Impact Hammer method. Therefore we specify a trigger level of e.g. 100 N. Each time the input signal overshoots the trigger level, the FRF calculation (FFT window) will start.

Excitation	Response	Transfer functions	Ge	eometry editor				
				Double hit detect		Time windows		
Pretrigger		Trigger level		Second hit lev	el	Window		Window length
1	~ %	100	N	1	Ν	Force	\sim	100

Trigger parameters used for e.g. Impact hammer test and burst shaker test.

Double hit detection

However, when the input signal shows multiple impulses after one hit (so-called double hits), <u>Dewesoft X</u> can identify this if you specify a double hit level. When the signal crosses the double-hit-level shortly after the trigger event, you will get a warning message and can repeat this measurement.

Excitation	Response	Transfer functions	G	eometry editor					
Trigger				Double hit detection	L	Time windows			
Pretrigger		Trigger level		Second hit level	I	Window		Window length	
1	~ %	100 N		20 N	J	Force	~	100	%

Double hit detection settings.

Overload level

You can also enable a warning which will be displayed when the hammer impact has exceeded a certain overload level - when the hit was too strong.

1.00													
l	Excitation	Response	Transf	er functions	Geometry edi	tor]						
	Trigger												
	Pretrigger		Trigger	level	Second	l hit	level	Windo	w		Window I	ength	
	1	~ %	100	N	I 20		Ν	Force	2	~	100		%
	20 samples												_
	Excitation c	hannels											
	\odot	Autofill		Search	۹		Show me	ssage if	excitatio	on exceeds 400) N]	
	Node ID	Direction	Sign	In	iput		Physical quan	itity	Units	Group		-	
	1	Z	+	Modal	Hammer		Force		N	1Z+			
	2	Z	+	Modal	Hammer		Force		N	2Z+			
	3	Z	+	Modal	Modal Hammer		Force		N	3Z+			

Overload level settings.

The following picture summarizes the different trigger level options.



Trigger level options

Now that we have defined the trigger condition, we should ensure that the FRF calculation covers our whole signal to get a good result.

Window length

Let's assume the sample rate of our example is 10 000 Hz and we have set 8192 lines in the FRF setup.

According to Nyquist, we can only measure up to half of the sample rate (5000 Hz) or the other way round, we need at least 2 samples per frequency line. So, our spectral line resolution is:

$$\Delta f = \frac{\text{Sample Rate}/2}{\text{Number of lines}} = \frac{5000 Hz}{8192} = 0.61 Hz$$

The whole FFT window calculation time (block length T) is:

$$T = \frac{1}{\Delta f} = \frac{1}{0.61Hz} = 1.64s$$

Measurement
Test method
Impact Hammer V
Roving hammer/response
FRF
Resolution
Spectral lines v 8192
lines: 8192, df: 0,61 Hz, duration: 1,64 s
Averaging type
Linear V
Stop after 4 avg.

Spectral line resolution

Below you see the cutout data section of the excitation and response signal, which covers pretty much the whole signal.

Note, that the x-axis is not starting at 0 but is scaled in samples from -819 to 15565 due to Pre-trigger settings. In total it gives 16384 samples for each FFT time block,







Pre-trigger

The Pre-trigger time defines how much time prior to the exceeded trigger level that should be included in the FFT blocks. From

the screenshot above you can see that 5% of 16 384 samples is 819 samples, which equals t pre = $819 \times (1/10\ 000\ Hz) = 81,9\ ms$. At sample 0 the trigger occurs.

Excita	tion	Response	Transf	er functions	Geometry edi	tor						
Trigge	r				Double hit	detection		vindows				
Pretrig 0,05	Pretrigger Trigger level		Second 20	Windo Force	Window Force ~			length	%			
0,1 0,2 0,5 1		tofil		Search	٩	Show me	essage if	excitatio	on exceeds 400) N		
L2 Node		Direction	Sign	In	put	Physical qua	ntity	Units	Group			
1		Z	+	Modal	Hammer	Force		N	1Z+			
2		Z	+	Modal	Hammer	Force		N	2Z+			
3		Z	+	Modal	Modal Hammer			N	3Z+			

Pre-trigger settings.

Modal Test Data Acquisition System Overview

In most of the cases acceleration sensors, microphones, modal hammers or other force transducers are used for analog input. If they are e.g. voltage or ICP/IEPE type, they are connected directly to the ACC amplifier of the <u>SIRIUS data acquisition system</u>, or <u>DEWE-43/MINITAUR</u> DAQ systems with Dewesoft smart sensor interface <u>DSI adapter</u> (DSI-ACC).

When analog output is needed (for shaker control), the SIRIUS analog out option (8 channels with BNC connector on the rear side of the <u>SIRIUS DAQ system</u>) provides a full-grown arbitrary function generator.



Modal Test DAQ system overview

Auto-generated Visual Displays

For an easier start, <u>Dewesoft</u> offers auto-generated displays, which already come with the most often used instruments and an arrangement that makes sense for them according to the type of application.

Dewesoft automatically makes 5 auto-generated displays, one for pre-test, 3 for measurements (one for each Test method) and one for analysis.

You should select the visual measurement display that relate to the Test method selected under the MT setup.



Modal Test displays.



Display template for Impact Hammer testing.

Information and Control section

At the upper left you find display widgets and control buttons that is used to manage the selected Test method. You have clear indication about the time data storing state, information about the measurement state at the current selected sensor groups, option to re-do the measurement at the current sensor groups, select which group of Node IDs that should be measured, and a progress table for the FRF functions to be determined.

Geometry section

At the lower left you find the Geometry widget that will by default show the geometry that was created or imported under the MT setup Geometry tab.

Excitation and response signal section

At the upper right you have the current selected excitation and response channels shown in 2D graph widgets both in time and frequency domain, (time scopes and FFT spectra).

FRF and coherence section

At the lower right you have 2D graphs showing the Frequency Response Functions (FRF) and Coherence Functions (COH).

Depending on the Test method selected the display widgets and controls will be different in order to have the best fit for the configured test. Hereby, there will be differences between all 5 pre-defined visual displays. Also if later on you make chances to the setup, then remember to re-build the visual display in order to update it accordingly to the newest setup changes. You can rebuild the displays by right-clicking on the MT display icon and press Re-build, as shown below:



How to re-build the Measure display templates.

Modal test info channels

There are additional channels provided by the FRF module, which give status information during the measurement. To display them, please add a Discrete display in Design mode:

		•	+	
fline math Auto recalculate	Save	Design	Widgets	Displays
I		Q	Favorites	All Ma
Meters			🦾 Camp	bell plot
26.3 Digital meter			<u> i a</u> 3D gr	aph obsolet
Analog meter			<u> i a</u> 3D gr	aph
Horizontal bar			2D/3	D table
Vertical bar			Controls	
ON Discrete display			👆 Input	t control
Indicator lamp			Video	

Adding	a	discre	te	disp	la١	1.

The channels 'Hit status' and 'OVLChannel' can be assigned to it. OVLChannel will only be displayed if the parameter 'Show message if excitation exceed' has been enabled under MT setup first.



Double hit warning.

FRF control channels

- During roving excitation or roving response measurements, after one group of Node IDs is measured, you can continue to the next group of Node IDs by pressing the Next group buttons.
- If you are unsatisfied with the last measurement, you can cancel it by using Reject last.
- If all measurements in a group must be re-measured, the Reset Group button can delete all the calculated data done for the current group of Node IDs at once.

All the actions are done using control channels in <u>Dewesoft</u>. If you want to create your own visual display then these controls can be modified manually by picking the input control display from the instrument toolbar. Set it to Control Channel and Pushbutton. Channels Reject last, Next point and Reset point can now be assigned from the channel list on the right.

	Ave Count ACT						
Storing	0						
Hit status; -							
No data							
Select excitation group INPUT	Select response group INPUT						
1Z+ ⊗	1Z+ ⊗						
Next excitation group	Next response group						
Reject last							
Reset group							

Modal test control buttons.

Force and Force + Exponential windows

When using triggered test methods like Impact hammer or shaker bursts then you can select between Force and Force + Exponential time windows.

The Window length parameter affects the excitation channels only since the response channels always have a window over the full FFT block length T.

The Window decay parameter is used for the Force + Exponential window type and defines the remaining relative amplitude at the end of the FFT block length.

Time windows				
Window	Window length		Window decay	
Force + Exponential ~	20	%	1	%
Force				
Force + Exponential				

Window functions and their settings for triggered modal tests.

Force window

A Force Window is a rectangular window with a certain length relative to the FFT block length T.

For Excitation channels the Window length can be adjusted/reduced to only include a part of the duration of FFT block length T, or 100 % of T. In our example the damping is very high (signal fades out quickly), therefore we can select a smaller portion of the signal, e.g. 10 % (usually you would define a noise level first to determine it). Having a window length of 100 % means that all of the acquired data will be taken for calculation (all 16 384 samples of the FFT block in our example from before, the whole block).

The response signals will always use a Window length of 100 % of the FFT block length T.



Force window type for excitation signals

Outside the Force window length the excitation signals will be cut out completely, in order to avoid noise.

Force + Exponential window

A Force + Exponential window will apply an exponential window on the excitation channels which has a length set by the Window length. After the defined Window length the exponential window drops to zero for the excitation signals.

The response channels will get an exponential window over the full FFT block length, T, no matter the setting for the Window length.

For both the excitation and response channels the Window decay percentage is relative to T.

â€[~]Force + Exponentialâ€[™] is commonly used for impact testing since it both reduces noise on the excitation and response channels, and keeps equal decay ratios between excitation and response channels inside the defined Window length, which avoids the need for additional window corrections.

The picture below shows how the response window is decayed when different Window decay percentages are selected in <u>Dewesoft</u>.



Window decay of response signals.

Averaging of spectra

The result can be improved by averaging the excitation and response spectra over a number of FFT blocks. Therefore, the first e.g. 5 hits in an Hammer Impact test will be recognized and taken into calculation for resulting averaged spectra. After the specified number of spectra are averaged then you move on to the next group of Node IDs.



Averaging of hits



Settings for averaging hits

Impact hammer, roving excitation sensor

Roving hammer SISO Modal Test



Roving excitation with a modal hammer. The reference response DOF is fixed.

In this operation mode, there is one acceleration sensor mounted in a fixed position on the structure. The modal hammer is moving through the excitation DOF points (e.g. doing 5 hits at each point, which are averaged). This is probably the most simple modal test and requires only one hammer and one response sensor. Using a single input excitation and a single output response is referred to as SISO testing - Single Input Single Output testing.

	Excitation	Response	Transf	er functions Geometry edit	tor								
Measurement	Trigger			Double hit									
Test method	Pretrigger		Trigger	level 🗹 Second	l hit level Win	dow		Window leng	th	Wind	ow decay		
Impact Hammer V	1	~ %	50	N 5	N For	ce + Expo	nential 🗸	100	9	% 1	%		
Roving hammer/response	20 samples	1											
	Excitation o	ccitation channels											
Resolution	\odot	Autofill	[Search Q	Show message	ifexcitatio	on exceeds 5	Ν					
Spectral lines v 1000	Node ID	Direction	Sign	Input	Physical quantity	Units	Group						
lines: 1000, df: 2,5 Hz, duration: 0,4 s	1	z	+	Impact Hammer	Force	N	1Z+						
Averaging type	2	z	+	Impact Hammer	Force	N	2Z+						
Stop after	3	Z	+	Impact Hammer	Force	N	3Z+						
8 avg.													
	Excitation	Response	Transf	er functions Geometry edi	tor								
Measurement	Response o	hannels											
Test method	$\mathbf{\Phi}$	Autofil	[Search Q									
Impact Hammer V	\odot												
Roving hammer/response	Node ID	Direction	Sign	Input	Physical quantity	Units	Group						
FRF	1	Z	+	Acc 1	Acceleration	g	1Z+						
Resolution													
Spectral lines V 1000													
lines: 1000, df: 2,5 Hz, duration: 0,4 s													
Averaging type Linear V													
Stop after 8 avg.													
L													

Roving excitation with an impact hammer setup.

Roving hammer SIMO Modal Test

If not all structural modes can be detected by using a single reference DOF (Node ID, Direction and Sign), then 2 or more response sensors can be used simultaneously at fixed references DOFs, while the modal hammer is roving. This is also referred to as MRIT - Multiple Reference Impact Test. When using a single input excitation and multiple output responses is referred to as SIMO testing - Single Input Multiple Output testing.



Roving excitation with a modal hammer. The 2 reference response sensors are fixed.

	Excitation	Response	Trans	fer functions Geometry ed	itor									
Measurement	Trigger			Double hit										
Test method	Pretrigger		Trigger	r level 🗹 Second	d hit level Window			Window le	ngth		Window decay			
Impact Hammer V	1	~ %	20	N 5	N Fo	rce + Expo	nential 🗸	100		%	1	%		
Roving hammer/response	20 samples	S												
FRE	Excitation	xcitation channels												
Resolution	\odot	Autofill		Search Q	Show message	e if excitati	on exceeds 5	N						
Spectral lines v 1000	Node ID	Direction	Sign	Input	Physical quantity	Units	Group							
lines: 1000, df: 2,5 Hz, duration: 0,4 s	1	Z	+	Impact Hammer	Force	N	1Z+							
Averaging type	8	Z	+	Impact Hammer	Force	N	8Z+							
	9	Z	+	Impact Hammer	Force	N	9Z+							
8 avg.														
	Excitation	Response	Trans	fer functions Geometry edi	tor									
Measurement		hannels												
Test method	$\mathbf{\Phi}$	Autofill		Search Q										
Impact Hammer V	00													
Roving hammer/response	Node ID	Direction	Sign	Input	Physical quantity	Units	Group							
ED E	1	Z	+	Acc 1	Acceleration	g	1							
Resolution	4	Z	+	Acc 2	Acceleration	g	1							
Spectral lines V 1000														
lines: 1000, df: 2,5 Hz, duration: 0,4 s														
Averaging type														
Linear V														
Stop after														
8 avg.														

The two reference response DOFs are in the same group to be measured at the same time.

Roving response SISO Modal Test



Fixed hammer excitation DOF and roving response DOF.

The hammer is always exciting the structure in the same DOF position (Node ID, Direction and Sign). Now the acceleration sensor is moved to different DOFs. The disadvantage of this setup is, that the mass of the acceleration sensor changes the structure differently in every point, therefore, influences the measurement (this effect is called mass loading). Also between each measurement, the sensor has to be mounted again, which results in a little more work than when using a roving hammer setup.

An advantage of using roving response testing is e.g. if it is difficult to impact the structure at all DOFs.

Using a single input excitation and a single output response is referred to as a SISO test, and if a group of multiple output responses are used (maybe a roving group) then it is referred to as a SIMO test.

		_									
	Excitation	Response	Transf	er functions Geometry edit	or						
Measurement											
Test method	Pretrigger		Trigger	level 🗹 Second	hit level Windo	w		Window length		Window decay	
Impact Hammer V	1	~ %	50	N 5	N Force	e + Expo	nential 🗸	100	%	1	%
Roving hammer/response	20 samples										
	Excitation c	hannels									
FRF	A	Autofil		Search O	Show message i	Fevritati	on exceeds 5	N			
Resolution	Θ	Autonii			Show message i	excitation					
Spectral lines V 1000	Node ID	Direction	Sign	Input	Physical quantity	Units	Group				
lines: 1000, df: 2,5 Hz, duration: 0,4 s	1	Z	+	Impact Hammer	Force	N	1Z+				
Averaging type		-									
Linear V											
Stop after											
8 avg.											
	Excitation	Response	Trans	fer functions Geometry edi	tor						
Measurement	Response o	hannels									
Test method	$\mathbf{\Phi}$	Autofil		Search Q							
Impact Hammer V	00		' '			1					
Roving hammer/response	Node ID	Direction	Sign	Input	Physical quantity	Units	Group	•			
ED E	1	z	+	Acc 1	Acceleration	g	1Z+				
Parking	4	Z	+	Acc 1	Acceleration	g	4Z+				
Resolution	5	7	+	Acc 1	Acceleration	-	57.1				
ispectral lines V 1000		-	Ŧ	Acci	Acceleration	9	324				
ines: 1000, dt: 2,5 Hz, duration: 0,4 s											
Averaging type											
Linear											
Stop after											
8 avg.											

Impact hammer and single roving accelerometer sensor SISO setup.

Shaker

Modal shakers are types of vibration shakers used to excite large or complex structures and to achieve high-quality modal data. In comparison to modal hammers, modal shakers have the ability to excite the structure in a broader frequency range, and with many different signal types, best suited for different structures and ideal for accurate test results. Shaker tests are often used for critical structures and when extended analysis is required. Shaker testing often use a large group of response sensors.

SIMO shaker setup



The channel setup of a SIMO shaker modal test is shown below:

	Excitation	Response	Trans	fer functions Geometry	editor							
Measurement	Excitation	settings										
Test method	Excitation	source	Excitat	Excitation type								
Shaker ~	External	~	Burst	~								
Roving response	Trigger			Time v	vindows							
FRF	Pretrigger		Trigger	level Windo	w	Window lengt	th	Window decay				
Resolution	1	~ %	20	N Force	e + Exponential 🗸	100	%	1	%			
Spectral lines V 1000	20 samples	20 samples										
lines: 1000, df: 2,5 Hz, duration: 0,4 s	Excitation	channels										
Averaging type	\odot	Autofill.		Search (Show message	ge if excitation	n exceeds 5	N				
Linear	Node ID	Direction	Sign	Input	Physical quantity	Units						
Stop after 30 avg.	1	Z	+	Shaker force 1	Force	N						
		_										
	Excitation	Response	Trans	fer functions Geometry	editor							
Measurement	Response c	hannels										
Test method	\odot	Autofill		Search C	L							
Roving response	Node ID	Direction	Sign	Input	Physical quantity	Units						
	1	Z	+	Acc 1	Acceleration	g						
Resolution	4	Z	+	Acc 2	Acceleration	g						
Spectral lines V 1000	5	Z	+	Acc 3	Acceleration	g						
lines: 1000, df: 2,5 Hz, duration: 0,4 s				1								
Averaging type Linear												

Modal shaker SIMO setup with one shaker and 3 response sensors.

MIMO Shaker setup



Modal Shaker MIMO test, with two input shakers and multiple response sensors.

The channel setup of a MIMO shaker modal test is shown below:

	Excitation	Response	Trans	fer functions Geometry edi	itor									
Measurement	Excitation	settings												
Test method	Excitation	source	Excitat	ion type										
Shaker ~	External	~	Burst	Burst V										
Roving response	Trigger	Trigger Time windows												
FRF	Pretrigger		Trigger	level Window	١	Nindow length		Window decay						
Resolution	1	~ %	20	N Force +	Exponential 🗸	100	%	1	%					
Spectral lines V 1000	20 samples	s												
lines: 1000, df: 2,5 Hz, duration: 0,4 s	Excitation channels													
Averaging type	\odot	Autofill		Search Q	Show messag	e if excitation ex	ceeds 5	N						
	Node ID	Direction	Sign	Input	Physical quantity	Units								
Stop after 30 avg.	1	Z	+	Shaker force 1	Force	N								
	8	Z	+	Shaker force 2	Force	N								
					·									
	Excitation	Response	Transf	er functions Geometry edit	tor									
Measurement	Response c	hannels												
Test method	\odot	Autofill.		Search Q										
Roving response	Node ID	Direction	Sign	Input	Physical quantity	Units								
EDE	1	z	+	Acc 1	Acceleration	g								
Resolution	4	Z	+	Acc 2	Acceleration	g								
Spectral lines V 1000	5	Z	+	Acc 3	Acceleration	g								
lines: 1000, df: 2,5 Hz, duration: 0,4 s	6	Z	+	Acc 4	Acceleration	g								
Averaging type	7	Z	+	Acc 5	Acceleration	g								
Linear V	8	Z	+	Acc 6	Acceleration	g								
Stop after 30 avg.	9	z	+	Acc 7	Acceleration	g								
	10	7	т.	Acc 8	Acceleration	-								

Modal shaker MIMO setup with two input force excitation channels and multiple output response channels
Shaker externally controlled

If the shaker is externally controlled, Dewesoft offers Burst mode (triggered acquisition) or Continuous mode (free-run acquisition):

Excitation settings			
Excitation source		Excitation type	
External	~	Burst	~
Trigger		Burst Continuous	

External excitation source types.

Continuous shaker excitation type

In Continuous mode spectra are calculated continuously as data are acquired throughout the measurement. A list of time weighting FFT windows for continuous signals are supported, and the calculated spectra can be set to overlap in time by specifying the Signal overlap parameter.

Excitation settings			
Excitation source		Excitation type	
External	\sim	Continuous	~
Continuous excitatio	on set	tings	
FFT window		Signal overlap	

External Continuous shaker excitation settings.

The calculation runs to the end of the measurement, but it can also be stopped automatically after a user-defined number of spectra by Checking on the $\hat{a} \in \mathbb{C}$ Stop after $\hat{a} \in \mathbb{C}$ parameter under FRF settings, and specifying a number of averages.

Burst shaker excitation type

In Burst mode the calculation of each spectrum is triggered by the externally controlled excitation signal. When the excitation input signal exceeds the Trigger level a new spectrum will be calculated. Depending on the ramp-up burst time, a Pre-trigger can be adjusted to ensure the FFT block of time samples, used for a spectrum, includes the entire burst.

Excitation settings			
Excitation source	Excitation type		
External \checkmark	Burst \vee		
Trigger		Time windows	
Pretrigger	Trigger level	Window	Window length
1 ~ %	100 N	Force ~	20 %

External Burst shaker excitation settings.

Time window functions for burst random signals are supported together with related user-defined window parameters. With triggered spectrum calculation Signal overlap is disabled since it is controlled by the trigger.

Shaker controlled by Dewesoft Analog Output

If the shaker is controlled with Dewesoft AO, we support Continuous random, Burst random and Sine sweep generator output excitation signals. AO is an abbreviation for Analog Output. All the settings for the function generator can be done directly in the Modal test setup.

Excitation settings								
Excitation source	Waveform							
Dewesoft AO 🛛 🗸	Continuous random 🛛 🗸							
AO soft start/stop Start time Stop time	Continuous random Burst random Sine sweep							
0,5 s 0,5	S							

Dewesoft analog output excitation waveforms.

For all Waveform types the AO soft start and soft stop times can be set. The soft start/stop times define the duration of half-sine leading and trailing gain tapers. The measurements will be calculated after the leading taper and before the trailing taper, except for triggered calculations when using Burst random.

In the Excitation channels table the Dewesoft AO channels to use must be selected, and their output voltage target amplitudes must be set. The Dewesoft output channels will have the defined voltage target amplitude over all frequencies.

Continuous random waveform

By selecting the Waveform type Continuous random, AO channels will output continuous random noise. The random noise will have a frequency Bandwidth equal to the Nyquist frequency of the DAQ device's sample rate, where the Nyquist frequency is given by:

$$f_N = \frac{f_{sample \ rate}}{2}$$

Burst random waveform

With Burst random Waveform type, the AO channels will output bursts of random signals with a user-defined burst length. The burst length (between the AO soft start and stop times) is set by the Excitation duration parameter. The excitation duration is specified in percent of the FFT time block length used for each spectrum:

Excitation	Response	Transfer functions	Geo	ometry editor		
Excitation settings						
Excitation so	ource	Waveform		Excitation durat	tion	
Dewesoft A	o ~	Burst random	\sim	60	% of segment	
	Excitation se Excitation se Excitation so Dewesoft A	Excitation Response Excitation settings Excitation source Dewesoft AO	Excitation Response Transfer functions Excitation settings Excitation source Waveform Dewesoft AO V Burst random	Excitation Response Transfer functions Geo Excitation settings Excitation source Waveform Dewesoft AO Burst random	Excitation Response Transfer functions Geometry editor Excitation settings Excitation source Waveform Excitation durated based	

FFT block length and relative duration of burst excitations.

Note: For minimum spectral leakage, remember to limit the Excitation duration enough to have room for the AO soft start/stop times in the FFT time blocks. Also, make sure the Pre-trigger is set such that the FFT time block includes the entire burst - from the beginning of AO soft start to the end of the AO soft stop:

	-	1	-		-
	Excitation	Response	Transfer functions	Geo	metry editor
Measurement	Excitation se	ttings			
Test method	Excitation so	ource	Waveform		Excitation duration
Shaker 🗸	Dewesoft A	o ~	Burst random	\sim	60 % of segment
Roving response	AO soft star	t/stop	Trigger		
FRF	Start time	Stop time	Pretrigger		Trigger level
Resolution	0,1 5	; 0,1	s 10	~ %	1 N
Spectral lines v 2500			500 samples		
lines: 2500, df: 1 Hz duration: 1 s	Excitation ch	iannels			

Bursts will (1) start after pre-trigger, (2) ramp-up over start time, (3) run over the excitation duration, (4) ramp-down over the stop time. The total duration should not exceed the FFT block duration.



Like for the Continuous random waveform, the bursts of random noise will have a bandwidth equal to Nyquist frequency of the DAQ device sample rate. For the Burst random waveform the window function is always rectangular/uniform.

Sine sweep waveform

The Sine sweep waveform outputs a sinusoidal signal that sweeps in frequency from Start freq. to Stop freq. over a specified Sweep time or with a specified Sweep rate. The frequency sweeping will begin after the AO soft start time and end before the AO soft stop time.

Swept sine testing will typically provide great coherence between input and output, and the total input force to the structure can be kept relatively low since only one frequency is excited at the time.

Excitation	Response	Transfer functions	ransfer functions Geometry editor								
Excitation source Waveform		Waveform		Start freq.		Stop freq.		Sweep type		Sweep time $$	
Dewesoft A	o ~	Sine sweep	\sim	10	Hz	100	Hz	Linear	\sim	60	s

Dewesoft AO Sine sweep excitation settings.

When using Sine sweep with multiple shakers, multiple sinusoidal sweeps have to be measured to be able to un-correlate the multiple input excitation signals. To be able to distinguish between the multiple excitation signals, the excitation pattern has to be different between the sweep runs.

In Dewesoft, this is managed by changing the phase pattern between sweep runs for the AO channels. Each sweep will have a phase profile containing the phase for each AO channel. The profiles can be set randomly by pressing the button Randomize profiles, or it can be set by the user in the Excitation channels table.

In order to un-correlate the excitation signals, at least the same number of sweep runs as the number of included AO channels must be used. The multiple phase profiles should be as different as possible to get best results.

For example using two AO channels the optimal phase profiles are 0Ű and 0Ű for run 1, and 0Ű and 180Ű for run 2. The measurements are averaged over all sweep runs, hereby measured data from all phase profiles are used for the spectral results.

Excitation	Response	Transf	er functions	Geometry edit	tor							
Excitation se	ettings											
Excitation s	ource	Wavefo	rm	Start fre	q.	Stop freq.		Sweep type	Sweep ti	me 🗸		
Dewesoft A	۰ v	Sine sw	eep	~ 10	Hz	100	Hz	Linear 🗸 🗸	60	s		
AO soft star	AO soft start/stop AO phase profiles Continuous excitation settings											
Start time Stop time Number of runs FFT window Signal overlap 0,5 s 0,5 s 2 Randomize profiles Hanning 66,7 %												
Excitation cl	hannels											
\odot	Autofill.		Search	۹	Sho	w message i	fexcitati	on exceeds 5	N			
Node ID	Direction	Sign	In	put	Physical	quantity	Units	AO chann	el	AO amplitude	Profile 1	Profile 2
1	Z	+	Shaker	Force 1	Fo	rce	N	Shaker sign	al 1	1,00 V	0,00 °	0,00 °
2	Z	+	Shaker	Force 2	Fo	rce	N	Shaker sign	al 2	1,00 V	0,00 °	180,00 °

Shaker Sine sweep modal test setup with two AO channels having different phase patterns for the two Profiles.

No phase profiles need to be configured for the random waveform types, since the excitation patterns between AO channels already change by the independent noise signals

You should ensure that the sweep is slow enough because the FFT needs some time T for calculation (dependent on the number of lines, resolution). The settings for the Dewesoft AO signals are the same as under the Function Generator module.

When you switch to Measure mode or press the Store button, the sweep will start.



Example of signals when doing a Shaker Sine sweep modal test.

When using a sine sweep, as the sweep moves through the frequencies, the graph data will be updated. Putting the AO/Freq channel on a separate display is a good way to show the current frequency.



The picture above shows two 2D graph instruments with transfer functions 2-1 and 3-1 (amplitude on top and the phase below) during a sweep. The left side is already calculated while the right side is ongoing.

ODS - Operating Deflection Shapes

Operating Deflection Shapes (ODS) is a simple way to do dynamic analysis and see how a machine or a structure moves within its operational conditions. ODS tests have no applied artificial forces and only response vibration signals are measured.

Dewesoft supports two ODS types:

- Time ODS used by adding a separate Time ODS module to your DewesoftX setup.
- Frequency ODS included in the Modal Test module as one of the Test methods.

Time ODS calculates deflection shapes over time, over a time axis, opposite to Frequency ODS which calculates deflection shapes over a frequency axis.

In this way, you can see how the overall structure deflects at a specific time instance with Time ODS, and you can see how the structure deflect at a specific frequency by using Frequency ODS.

Time ODS

The time ODS module can be added to the setup file like shown in the picture below:



Adding the Time ODS module to the setup.

In the Time ODS setup you can select vibration channels as inputs, being acceleration, velocity or displacement channels, and you can Integrate or differentiate them to obtain e.g. displacement as the output quantity. A geometry can be created in the same way as in the MT module.

Time ODS +													
	Respons	Responses Geometry editor											
Output settings	Response	channels											
Output type	$\mathbf{\Theta}$	A	utofill										
Displacement \checkmark	Index	Node ID	Direction	Sign	Input	Physical quantity	Units	Scaling					
Output unit	1	0	Z	+	Acc 1	Acceleration	m/s2	39,3700					
in v	2	0	Z	+	Acc 2	Acceleration	m/s2	39,3700					
Filter low frequencies and DC	3 0		Z	+	Acc 3	Acceleration	m/s2	39,3700					
Filter order Cut off frequency 4 0,1													

Time ODS setup.



A Time ODS measurement being replayed in Analyse mode.

For more information about Time ODS please use the following links:

- Time ODS Online Help
- Modal Test and Analysis Manual Time ODS section

Frequency ODS

When performing Frequency ODS, one of the accelerometers has to be set at a reference channel in order to calculate phase information. In Dewesoft this is done by selecting the reference response sensor as an excitation channel. The reference channel should be placed at the DOF revealing the most structural modes.

		Excitation	Response	Transfe	er functions	Geometry edit	or				
Measurement		Continuous e	excitation set	ttings							
Test method		FFT window		Signal ov	/erlap						
ODS 🗸		Blackman	~	66,7	~	%					
Roving response											
FDF		Excitation channels									
Resolution	\odot										
Spectral lines V 1000	Node ID	Direction	Sign	In	put	Physical quantity	Units				
lines: 1000, df: 2,5 Hz, duration: 0,	1	z	+	A	c 1	Acceleration	m/s2				
Averaging type	-	-									
Linear 🗸	E sette Ke	- Deener			. C						
Stop after	Excitatio	n Respon	se Tra	nster tunction	s Geometry (editor					
20 avg.		Response	Channels				-				
		$\mathbf{\Phi}$	Auto	fill	Search	Q					
Output channels		Node ID	Direction	Sign		Input	Physical quantity	Units			
Output	Used	1	Z	+		Acc 1	Acceleration	m/s2			
H1 transfer functions	Used	2	Z	+		Acc 2	Acceleration	m/s2			
H2 transfer functions *	Unused	3	Z	+		Acc 3	Acceleration	m/s2			
Ordinary coherence	Used	4	Z	+		Acc 4	Acceleration	m/s2			
Multiple coherence *	Unused	5	Z	+		Acc 5	Acceleration	m/s2			
Power spectral density Unused		6	Z	+		Acc 6	Acceleration	m/s2			
Ordinary mode indicator function Unused		7	Z	+		Acc 7	Acceleration	m/s2			
Intermediate Fourier transforms	Unused	8	Z	+		Acc 8	Acceleration	m/s2			

ODS test setup with one of the output sensors assigned as a reference channel on the excitation tab.

In you want to group your sensors and move them during the measurement, select option Roving response.

This will create different groups and you can manually select the sensors in the same group or change group names.

	Excitation	Response	Transf	er functions Geometry	editor		
Measurement	Response c	hannels					
Test method ODS	\odot	Autofill		Search C	L.		
Roving response	Node ID	Direction	Sign	Input	Physical quantity	Units	Group
FRF	1	Z	+	Acc 1	Acceleration	m/s2	Group 1
Resolution	2	Z	+	Acc 2	Acceleration	m/s2	Group 1
Spectral lines V 1000	3	Z	+	Acc 3	Acceleration	m/s2	Group 1
lines: 1000, df: 2,5 Hz, duration: 0,4 s	4	Z	+	Acc 4	Acceleration	m/s2	Group 1
Averaging type	5	Z	+	Acc 1	Acceleration	m/s2	Group 2
	6	Z	+	Acc 2	Acceleration	m/s2	Group 2
20 avg.	7	Z	+	Acc 3	Acceleration	m/s2	Group 2
	8	Z	+	Acc 4	Acceleration	m/s2	Group 2

Roving ODS test setup with two groups containing the same 4 channels but at different DOF Node IDs.

During the measurement, you can switch between the groups:



ODS test example, showing Group 1 being measured and Group 2 still waiting to be measured.

[Video available in the online version]

EMA - Experimental Modal Analysis

In the experimental modal analysis (EMA), the structures are excited by artificial forces and both the inputs (excitation) and outputs (response) are measured to get the frequency response functions (FRF) or impulse response functions (IRF) by digital signal processing. Modal parameters can be identified from FRF or IRF by identification algorithms in the frequency domain or the time domain. EMA tests are usually carried out in the lab, with the advantage of high signal to noise ration (SNR) and easy to change test status.

EMA identification methods can be classified into a time domain (TD) methods and frequency domain (FD) methods according to different identification domain. Also, they can be classified according to a different number of input and output:

- SISO (single input single output),
- SIMO (single input multiple outputs),
- MIMO (multiple inputs multiple outputs).

The FRF is generally utilized for the EMA in the frequency domain, which is estimated from the excitation and response signals. Then the modal parameters are identified by constructing the parametric or nonparametric models of the FRF and curve fitting them. The IRF is generally utilized for the EMA in the time domain. It can be obtained from the inverse FFT of FRF.

Time domain methods are suitable for the global analysis in a broad frequency band, which have good numeric stability. However, there are some limitations too:

- · very difficult to confirm the order of math model,
- always time-consuming,
- · many calculation modes got with the structural modes and difficult to delete them,
- many settings needed, complicated-to-use,
- not being able to take into account the influence of out-band modes.

On the opposite side, frequency domain methods are always reliable, rapid, easy-to-use, with the capacity to consider the outband modes and analysis uneven spaced FRFs, so they are applied widely.

OMA - Operational Modal Analysis

Operational modal analysis is used for large civil engineering structures, operating machinery or other structures, making use of their output response only. These structures are always loaded by natural loads that cannot easily be controlled and measured, for instance, load from waves (offshore structures), the wind loads (buildings) or traffic loads (bridges).

Both OMA and ODS only use output response channels, but where ODS mainly provide deflection shapes for animation, OMA provides a modal model like EMA (Experimental Modal Analysis) does, which includes resonance frequencies, damping ratios and mode shapes of simple and complex structures.

When it is possible EMA is typically preferred over OMA as the best modal test type due to the controlled environment, where the operator can manage the structural excitations. But, in cases where it is difficult to excite the structure by artificial means, OMA is a great way to go. Moreover, all the measured responses come under operational state of structures, and their real dynamic characteristics in operation could be revealed, so OMA is very suitable for health monitoring and damage detection of large-scale structures.

MIMO - multiple shaker excitation

Multiple-Input Multiple-Output (MIMO) measurement techniques are a well-proven and well-established method for collecting FRF data sets. MIMO methods offer some distinct advantages for the measurement and extraction of basic modal parameters especially while testing larger structures.

The main advantage of MIMO is that the input-force energy is distributed over more locations on the structure. This provides a more uniform vibration response over the structure, especially in cases of large and complex structures and structures with heavy damping. In order to get sufficient vibration energy into these types of structures, there is a tendency to overdrive the excitation DOF when only a single shaker is used. This can result in non-linear behavior and deteriorates the estimation of the FRFs. Excitation in more locations often also provides a better representation of the excitation forces that the structure experiences during real-life operation.

The response transducers must be roved around unless there are sufficient transducers available to cover all the response DOFs. With this type of testing, uncorrelated random (continuous, burst, or periodic random) excitation signals are used. Burst random and periodic random signals have the ability to provide leakage-free estimates of the FRFs, i.e., without resolution-bias errors, which is an advantage compared to continuous random signals.

A demo measurement was done on a plane model. The structure was excited by two shakers with uncorrelated excitation signals. The responses were measured with 3-axial accelerometers and the excitation signals were measured with force transducers. The voltage signal for the shakers was supplied from the Dewesoft Function generator (AO module).



MIMO measurement on a demo airplane

On the left side of the Modal test UI, you select Shaker as a test method, resolution of the measurement, and additional output channels.

On the right side of the UI, define the excitation source and excitation channels. We will use Dewesoft AO to drive the shakers and we select Burst random noise as the type of excitation.

We will measure the excitation with 2 force transducers in Z+ direction, at points 1 and 2.

MT +								Used	✓ Setup	~	Rename	
Development of the set of the stand buy as low letters	black locath and an altim	Defens changing fields like FC	Things Char after Views Destrie	T-i I			blash.					
does not include next trigger or spans too much	into calculation of next ro	oving group.	T Lines, Stop after X avg., Pretrig	ger, migger i	everand Overlap make su	re, that calculation	DIOCK					
	Excitation Respon	nse										
Measurement	Excitation settings											
Test method	Excitation source	Waveform	Excitation duration									
Shaker V	Dewesoft AO	✓ Burst random ✓	50 % of segmen	nt								
Roving response	Trigger											
FRF	Pretrigger	Trigger level										
Resolution		% 1 N										
Spectral lines V 4096	U samples											
Ines: 4096, dt: 0,61 Hz, duration: 1,64 s					1 E N							
Linear ~	Autofi	II Search		e ir excitatio	in exceeds 5							
Stop after	Index Direction	Sign Input	Physical quantity	Units	AO channel	AO amplitude	AO offset	AO phase				
4 avg.	1 Z	+ Force :	Force	N	AO 1	1,00 V	0,00 V	0,00 °				
	2 Z	+ Force 2	Force	N	AO 2	1,00 V	0,00 V	0,00 °				
Output channels												
Output Used												
H1 transfer functions Used												
H2 transfer functions * Used												
Ordinary coherence Unused												
Multiple coherence * Used	Signal preview											
Power spectral density Unused	Display options				Sign	al preview						
Ordinary mode indicator function Used	Window_											
Intermediate Fourier transforms Used	✓ Input	~{ £										
	Trigger level	ॄ_J┋ _┲ ╞────										
Outputs marked with * require a lot of		b b b b c c c c c c c c c c										
computing power. Consider disabling them during measurement and enabling them in		~ (월 등)										
analysis mode.		33 49										
		0,0		500,0	v		1000,0			150	0,0 163	8,2
		Preview graph is not available	in analysis mode.		~	1/13-(1113)						

Image 54: MIMO setup - excitation channels

We measured the responses with 4 tri-axial accelerometers in X, Y, and Z direction (points 1, 2, 4, 5) and with 2 uni-axial accelerometers in Z direction (points 3 and 6). Setup was done accordingly, as shown in the image below.

Rescionalist result are affected by calculation block ingth and position. Before changing fields like FFT Lines, Stop after X arg., Pretrigger Crigger level and Overlap make sure, that calculation block Rescionalist result are affected by calculation block ingth and position. Before changing fields like FFT Lines, Stop after X arg., Pretrigger Crigger level and Overlap make sure, that calculation block Rescionalist result are affected by calculation block ingth and position. Before changing fields like FFT Lines, Stop after X arg., Pretrigger Crigger level and Overlap make sure, that calculation block Rescionalist rescionalist of field crigger group. Rescionalist rescionalin rescinalist rescionalist rescionalist rescionalist rescionalist	MT +									Used	✓ Setup	~	Rename	130
Bese not include next trigger or spans too much into calculation of next trigger or spans too much into calculatitrigger or spans too much into calculation of next trigger or spa	Recalculated results are affected by	v calculation I	block length a	and position. E	Before cha	anging fields like FFT Lines. Str	op after X avo Pretrigo	er. Trigger	level and Overlap make sure, that calculation block		1.1.14			
Excitation Response Pleasavement Pleasavement Pleasavement <td< td=""><td>does not include next trigger or spa</td><td>ns too much i</td><td>nto calculatio</td><td>n of next rov</td><td>ing group.</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></td<>	does not include next trigger or spa	ns too much i	nto calculatio	n of next rov	ing group.									
Itest method Itest method I cest method I cest cest cest ceston I ce			Excitation	n Respons	e									
I eterhod Shaker Roving response I Koving response I Kaving response I K	Measurement		Response	channels										
Index Direction Sign Input Physical quantity Units I X + Acx X 1 Acceleration m/sz Rescultorin 1 Y + Acx X 1 Acceleration m/sz Spectral lines: 4096 1 Z + Acx Z 1 Acceleration m/sz Averaging type 2 X + Acx Y 2 Acceleration m/sz 1 Unex - Acx Y 2 Acceleration m/sz 2 Y + Acx Y 2 Acceleration m/sz 3 Z + Acx Y 3 Acceleration m/sz 4 Y + Acx Y 4 Acceleration m/sz 1 transfer functions * Used + Acx Y 5 Acceleration m/sz Chanyu coherance * Used - + Acx Y 5 Acceleration m/sz Power spectral density Unued - + Acx Y 5 Acceleration m/sz Ordnaryu coherance * Used - +<	Test method		Θ	Autofill.		Search Q								
Image: Second	Roving response		Index	Direction	Sign	Input	Physical quantity	Units						^
1 Y + Acc Y 1 Acceleration m/s2 Becolution 4096 1 Z + Acceleration m/s2 Verraging type 2 X + Acceleration m/s2 2 Y + Acceleration m/s2 3 Z2 + Acceleration m/s2 3 Z2 + Acceleration m/s2 4 X + Acceleration m/s2 4 X + Acceleration m/s2 4 Y + Acceleration m/s2 5 X + Acceleration m/s2 5 X + Acceleration m/s2 5 Y + Acceleration m/s2 5 Y + Acceleration m/s2 5 Y	soc.		1	x	+	Acc X 1	Acceleration	m/s2						
Spectral lines: 4096 Ines: 4096/ Ines: 4096/ Ines: 4096/ Spectral lines: 4 Verging type 2 Ines: 2 Stop after 4 2 4 X 4 X 4 X 4 X 4 Y 4 X 5 X 4 X 5 X 4 X 5 X 4 X 5 X 4 X 5 X 4 X 5 X 4 X 5 X 6 Y </td <td>Resolution</td> <td></td> <td>1</td> <td>Y</td> <td>+</td> <td>Acc Y 1</td> <td>Acceleration</td> <td>m/s2</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	Resolution		1	Y	+	Acc Y 1	Acceleration	m/s2						
Ines: 4096, df: 0,61 Hz, duration: 1,64's Averaging type Linear Stop after 4 avg. 0utput channels 0utput linear 0utput linear 0utput linear 4 X + Acceleration m/s2 3 Z + Acceleration m/s2 4 X + Acceleration m/s2 4 X + Acceleration m/s2 Stop after 4 Y + Acceleration m/s2 Stop after 4 Y + Acceleration m/s2 Stop after H1 transfer functions Used Power spectral density Unued Ordinary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with "reguire a lot of computing power. Consi	Spectral lines v 4096		1	Z	+	Acc Z 1	Acceleration	m/s2						
Averaging type 2 Y + Acceleration m/s2 Stop after avg. 2 Z + Acceleration m/s2 3 Z + Acceleration m/s2 4 X + Acceleration m/s2 4 X + Acceleration m/s2 4 Y + Acceleration m/s2 5 X + Acceleration m/s2 0rdinary mode indicator function Used * * * Multiple coherence * Used Used * * * 0utputs marked with * require a tot of computing power. Conside find tabing them * *	lines: 4096, df: 0,61 Hz, duration:	1,64 s	2	x	+	Acc X 2	Acceleration	m/s2						
1 2 Z + Acceleration m/s2 3 Z + Acceleration m/s2 3 Z + Acceleration m/s2 4 X + Acceleration m/s2 4 Y + Acceleration m/s2 5 X + Acceleration m/s2 5 Y + Acceleration m/s2 Multiple coherance * Used Used Used Used Intermediate Fourier transforms Used Used Used Used Outputs marked with * require a lot of computing power. Conside f	Averaging type		2	Y	+	Acc Y 2	Acceleration	m/s2						
3 Z + Acceleration m/s2 0utput channels 4 X + Acceleration m/s2 4 Y + Acceleration m/s2 5 X + Acceleration m/s2 5 Y + Acceleration m/s2 6 Y + Acceleration m/s2 9 Y + Acceleration m/s2 1 Y + Acceleration m/s2 9 Y + Acceleration m/s2 1 Y + Acceleration m/s2 <td>Linear V</td> <td></td> <td>2</td> <td>Z</td> <td>+</td> <td>Acc Z 2</td> <td>Acceleration</td> <td>m/s2</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td>	Linear V		2	Z	+	Acc Z 2	Acceleration	m/s2						
Image: Construction of the state of the	Stop after		3	z	+	Acc Z 3	Acceleration	m/s2						
Output Used 0utput Used H1 transfer functions Used H2 transfer functions** Used Ordnary coherence Unused Multiple coherence** Used Power spectral density Unused Ordnary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with * require a lot of computing power. Consider fiscibiling them Implementation	avy.		4	x	+	Acc X 4	Acceleration	m/s2						
Output Used H1 transfer functions Used H2 transfer functions** Used H2 transfer functions** Used Ordinary coherence Unused Multiple coherence * Used Power spectral density Unused Intermediate Fourier transforms Used Outputs marked with * require a lot of computing power. Consider finabiling them Image: Computing power. Consider finabiling them	Output channels		4	Y	+	Acc Y 4	Acceleration	m/s2						
H 1 transfer functions Used H2 transfer functions ** Used Ordinary coherence Unused Multiple coherence ** Used Power spectral density Unused Ordinary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with * require a lot of computing power. Consider fashing them Image: Computing power. Consider fashing them	Output	Used	4	Z	+	Acc Z 4	Acceleration	m/s2						
H2 transfer functions * Used Ordinary coherence Unused Multiple coherence * Used Power spectral density Unused Ordinary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with * require a lot of computing power. Consider disabiling them Image: Computing power. Consider disabiling them	H1 transfer functions	Used	5	x	+	Acc X 5	Acceleration	m/s2						
Ordnary coherence Unused Multiple coherence * Used Power spectral density Unused Ordnary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with * require a to of computing power. Consider disabiling them	H2 transfer functions *	Used	5	Y	+	Acc Y 5	Acceleration	m/s2						
Multiple coherence * Used Signal preview Power spectral density Unused Ordinary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with * require a to fr Input	Ordinary coherence	Unused	-	7		A 7 F	*	/- 7						~
Power spectral density Unused Display options Image: Consider disabiling them Ordnary mode indicator function Used Image: Consider disabiling them Image: Consider disab	Multiple coherence *	Used	Signal pre	view										-
Ordinary mode indicator function Used Intermediate Fourier transforms Used Outputs marked with * require a lot of computing power. Consider disabling them	Power spectral density	Unused	Display op	otions 🔳					Signal preview					
Intermediate Fourier transforms Used	Ordinary mode indicator function	Used	Windo	w	101	74 								
Outputs marked with * require a lot of computing power. Consider disabling them	Intermediate Fourier transforms	Used	Input 🗹	_	e te									
during measurement and enabling them in analysis mode.	Outputs marked with * require a lot computing power. Consider disabili during measurement and enabling analysis mode.	t of ng them them in			Vindow coeffic	,,,,,,,		500.0				1500	0 163	8,2

Image 55: MIMO setup - response channels

On time-domain recorder (top right corner) you can see time domain channels from excitation and responses.

On the left side, the results are displayed on 2D graphs. You can see transfer functions, coherences, and MIF (mode indicator functions). The geometry is animated from the selected frequency.



Image 56: MIMO results

Transfer functions setup tab

The transfer functions tab gives an overview of which transfer functions that will be calculated. For large test setups involving many sensor locations and multiple references the full set of transfer functions can be big. If not all transfer functions are required while performing measurements they can be toggled from â€~Usedâ€[™] to â€~Unusedâ€[™] to increase the performance. In Analyze mode, when doing post-analysis, the â€~Unusedâ€[™] transfer functions can be toggled back to â€~Usedâ€[™] and recalculations can be done based on the acquired time data.

Excitation	Response	Tra	ansfer functions	Geometry editor			
Transfer fun	ctions						
Response	es \Excitations	s		1Z+ (group 12	(+)		
				Used			
1Z+ (gr	oup Group 1)		Used	1Z+/1Z+			
2Z+ (gr	oup Group 1)		Used	2Z+/1Z+			
3Z+ (gr	oup Group 1)		Unused	3Z+/1Z+			
4Z+ (gr	oup Group 1)		Used	4Z+/1Z+			

Transfer functions setup tab example, with one excitation

channel and 4 response channels, giving 1 x 4 transfer

functions.

Geometry editor setup tab

Under the Geometry editor tab you can create or import a geometry that relates to the test. The geometry is mapped to the channels via the Node IDs. After connecting all nodes to channels the geometry can animate mode shapes and defection shapes depending on the used Test method.

For additional information about how to use the Geometry editor please look at:

- Geometry online help page
- Modal test and analysis manual

				in functions		And a diam.												
Exci	itation	Response	Transf	er funcuons	Geome	try editor												
Resp	onse c	hannels																
Ð	Θ	Autofill.		Search		٩												
Nod	le ID	Direction	Sign		Input		Physical q	uantity	Units	Group								
	1	z	+		Acc 1	_	Acceler	ation	m/s2	Group 1	_							
	2	z	+		Acc 2		Accelera	ation	m/s2	Group 1	_							
	3	z	+		Acc 3		Accelera	ation	m/s2	Group 1	-							
	4	z	+		Acc 4		Accelera	ation	m/s2	Group 1	_							
	5	Z	+		Acc 1		Accelera	ation	m/s2	Group 2	-							
	6	Z	+		Acc 2		Accelera	ation	m/s2	Group 2	_							
	7	z	+		Acc 3		Accelera	ation	m/s2	Group 2	_							
	8	z	+		Acc 4		Accelera	ation	m/s2	Group 2								
Exci Geon File	itation netry e Too	Response editor ols	Transf	er functions	Geome	try editor			-					_				
Exci Geon File Obje	itation netry e Toc ects	Response editor ols Nodes Lin	Transf	faces	Geome	try editor]	Add Cart	tesian CS	Add Cylindric	cal CS					~7		
Exci Geon File Obje + I	itation netry e ects	Response editor ols Nodes Lin Show t Node ID	Transf	faces ints	Geome	try editor X angle	Y angle	Add Cart Z angle	tesian CS Object	Add Cylindric	cal CS					~		
Exci Geon File Obje + I	itation netry e ects	Response editor ols Nodes Lin Nodes D Node ID	Transf es Sur unused po X 0,00	faces ints 0,00	Geome Z 0,00	try editor X angle	Y angle 0	Add Cart Z angle 0	tesian CS Object	Add Cylindric State	cal CS						3	
Exci Geon File Obje + I	itation netry e ects (. Car	Response editor ols Lin Nodes Lin Node ID rtesian CS[1	Transf les Sur unused pc X 0,00 0,00	faces of the second sec	Geome Z 0,00 0,00	X angle	Y angle 0 0	Add Cart Z angle 0 0	esian CS Object 1	Add Cylindric State Measured	cal CS				4			
Exci Geon File Obje + I	itation netry e ects (. Car 0	Response editor ols Lin Nodes Lin Node ID rtesian CS[1 2	Transf es Sur unused po X 0,000 0,000 0,000	Faces	Geome Z 0,00 0,00 0,00	X angle 0 0 0	Y angle 0 0 0	Add Cart Z angle 0 0 0	esian CS Object 1 1	Add Cylindric State Measured Measured	cal CS				3	2		
Exci Geon File Obje + I	itation netry e ects (. Car 0 1	Response editor ols Nodes Lin Show to Node ID rtesian CS[1 2 3	Transf ies Sur unused po X 0,000 0,000 0,000 0,000 0,000 0,000	Faces ints 0,00 0,67 1,33	Geome Z 0,00 0,00 0,00 0,00	X angle 0 0 0 0 0	Y angle 0 0 0 0 0	Add Cart Z angle 0 0 0 0 0	Object 1 1 1	Add Cylindric State Measured Measured Measured	cal CS	Î	z		3		7	
Exci Geon File Obje + I	itation netry e ects Car Car 1 2 3	Response aditor Nodes Lin Nodes Lin Node ID rtesian CS[1 2 3 4	Transf ies Sur unused pc X 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00	Faces ints V 0,00 0,67 1,33 2,00	Geome Z 0,00 0,00 0,00 0,00 0,00 0,00 0,00	X angle 0 0 0 0 0 0 0 0	Y angle 0 0 0 0 0 0 0 0	Add Cart Z angle 0 0 0 0 0 0 0 0	esian CS Object 1 1 1 1	Add Cylindric State Measured Measured Measured Measured	cal CS	Î	z	×2		2		
Exci Geom File Obje + I	tation netry e cts	Response editor ols Nodes Lin Node ID rtesian CS[1 2 3 4 5	Transf es Sur unused pc X 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 1,00 1,00	Faces ints Y 0,00 0,00 0,67 1,33 2,00 0,00	Geome Z 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00	X angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Y angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Add Cart Z angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0	besian CS Object 1 1 1 1 1 1 1 1	Add Cylindric State Measured Measured Measured Measured Measured	cal CS		z	F ₂	3			
Exci Geon File Obje + I	tation netry e cts Car Car Ca 1 2 2 3 3 4	Response editor ools Lin Nodes Lin Node ID rtesian CS[1 2 3 4 5 6	Transf es Sur unused po 0,00 0,00 0,00 0,00 1,00 1,00	Faces ints V V 0,00 0,00 0,67 1,33 2,00 0,00 0,00 0,67	Geome Z 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00	X angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Y angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Add Cart Z angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	besian CS Object 1 1 1 1 1 1 1 1 1 1	Add Cylindric State Measured Measured Measured Measured Measured Measured	cal CS	Ĩ	z		3			
Exci Geon File + I 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	tation netry e ccts	Response editor ols Lin Nodes Lin Node ID rtesian CS[1 2 3 4 5 6 7	Transf es Sur unused po 0,000 0,000 0,000 0,000 0,000 0,000 0,000 1,000 1,000	rfaces ints 0,00 0,00 0,67 1,33 2,00 0,00 0,67 1,33	Geome Z 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00 0,00	X angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Y angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Add Cart Z angle 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	besian CS Object 1 1 1 1 1 1 1 1 1 1 1	Add Cyindric State Measured Measured Measured Measured Measured Measured Measured Measured	cal CS		z	F ₂				

Mapping of sensors to the geometry by Node IDs.

The geometry can be managed in the Modal Test setup under the Geometry editor tab, or in Measure we can add the "Modal Geometry†widget.

When the Geometry editor tab is used under the Modal Test setup, the geometry are automatically shown on the pre-defined measure displays for MT.



Geometry widgets can be added to userdefined measure displays.

Importing geometries

You can Import UNV / UFF (universal file format) geometries from other software (e.g. MEScope or Femap) into <u>Dewesoft X</u>. Of course, you can also import a geometry that was drawn in <u>Dewesoft X</u>'s FRF Editor before. You can also use Load to open geometries from XML files.

On the Geometry tab on the Modal test setup, or from the properties of the Modal geometry widget on the left, select Load of Import.



Importing a geometry to the Modal Test setup.

Drawing a structure

To draw a structure go to the Geometry editor tab in the Modal Test setup. In the editor we can add Objects, Nodes, Lines and Surfaces. All the points and objects can individually be defined in a Cartesian coordinate system or Cylindrical coordinate system.

Exc	citation	Response	Transfer fur	nctions	Geometry ed	litor				
Geo	ometry	editor								
File	ie To	ools								
Ob	hiects	Nodes Line	s Surfaces							
	Jeets		s canaces							
4	ÐG) Show un	nused points				Add Ca	rtesian CS	Add Cyli	indrical CS
+	Ι.	Node ID	X	Y	Z	X angle	Y angle	Z angle	Object index	State
4	Ca	artesian CS[-1	0,00	0,00	0,00	0	0	0		
	0	1	1,00	0,00	0,00	0	0	0	1	Measured
	1	2	1,00	1,00	0,00	0	0	0	1	Measured
	2	3	2,00	0,00	0,00	0	0	0	1	Measured
	3	4	2,00	1,00	0,00	0	0	0	1	Measured

Example of a plate Object in the Geometry editor tab, having 4 nodes.

Objects

The structure can be assembled from pre-defined objects. The object that are available in the Geometry editor are:

- Cuboid
- Plate
- Circle
- Sphere
- Cylinder
- Cone

For each object you can define the position (X, Y and Z coordinate), size (of axis) and number of points in each axis. If the user selects option Surfaces, the surfaces will automatically be assigned to the structure.

Excitation Resp	onse Trar	nsfer functions	Geometry editor			
Geometry editor						
File Tools						
Objects Nodes	Lines 5	Surfaces				
$\oplus \Theta$						
· Index Turns	News	v	v	7	E dia	
+ Index Type	Name	X	r	۷	Edit	
Edit obje	a l					×
Object						
Plate		~				
Cuboir	d			_	_	
Po Plate Circle			v.	0 7:		
Spher	a		r:	0 2;	0	
Or Cylind Cone	er					
XY		~				
Size						
Size on	first axis:	1	Size on second axis:	1		
Number	of points					
Points	on first axis:	2	Points on second axis:	2		
				<u> </u>		
						OK
Sur	faces					UK



Example of some objects created by the object editor.

How to enter the object editor.

Nodes

Under the Nodes tab in the Geometry editor you can link the channels, used in the setup, to the geometry. The setup channel Node ID numbers are linked to the geometry Node ID numbers. Nodes are points where the sensor is positioned on an object.

Nodes are defined with location (X, Y, Z) and rotation around axes (X angle, Y angle, Z angle). In order to create a new structure from nodes, we have to switch to the Nodes tab. Now we have to create a coordinate system in which we will define our nodes. This can either be Cartesian or Cylindrical. After the coordinate system is created, we can add nodes with the Plus button.

After nodes are created we can change their rotation (according to how the sensor is rotated on the object) with all three axes. Nodes can be selected with selection in the node table or with the right mouse click on the structure preview window. When a node is selected, rotation is shown with a small coordinate system located directly on the node. In the picture below you can see a selected and rotated node.

ł	+	I.	Node ID	X	Y	Z	X angle	Y angle	Z angle	State
	4		Cartesian CS[-1] Center Point	0,00	0,00	0,00	0	0	0	
		0	1	0,00	0,00	0,00	0	0	0	Measured
		1	2	0,00	2,00	0,00	0	0	0	Measured
		2	3	1,14	0,00	0,00	0	0	0	Measured
0		3	4	1,14	2,00	0,00	0	0	0	Measured
1		4	5	2,29	0,00	0,00	0	0	0	Measured
		5	6	2,29	2,00	0,00	0	0	0	Measured
		6	7	3,43	0,00	0,00	0	0	0	Measured
		7	8	3,43	2,00	0,00	0	0	0	Measured
e		8	9	4,57	0,00	0,00	0	45	0	Measured
		9	10	4,57	2,00	0,00	0	0	0	Measured
		1.	11	5,71	0,00	0,00	0	0	0	Measured



Selected rotated node point.

Lines

When nodes are defined we can go ahead and manually add lines to connect them. An easy way to create lines is to right click with the mouse on the node, select Add -> Lines.



Adding lines between node points.

Left click on the first node and move to the second node. This will create a white line and when you hover to the node, the line will change to green color. Select the second node and the line will be added. You can add multiple lines consecutively. Right mouse click will stop adding lines.

If we donâ€[™]t want to draw a connected line, we can also manually add lines by pressing on the Plus button in Lines tab of the Geometry editor.

Surfaces

Surface can be defined with 3 nodes. Triangle surfaces can be added with a right mouse click on a node point, Add -> Triangles.



Adding surfaces between node points.

Triangle surfaces can also be added by clicking the plus button and manually defining corners.

Cartesian coordinates

Cartesian coordinates Usually nodes are presented with a Cartesian coordinate system. This means you have X, Y, Z position and rotation around all three axes. Coordinate system can be used for grouping nodes, because you can later rotate or translate them with the Center point.

Cylindrical Coordinates

Cylindrical coordinate system is used for easier creation of round objects. Points are defined with radius, angle and z (height) around coordinate systems center point. Cartesian and cylindrical CS can be combined in one geometry.

Importing a CAD file into Dewesoft X's geometry editor

When it comes to importing a more complex geometry into the <u>Dewesoft X</u>'s FRF geometry editor, the number of nodes can be very large. If you are using a CAD software solution that do not support export to UNV and do not support reduction in the number of node points, then you can find a freeware-converter GMSH from e.g. STL-to-UNV here: <u>http://geuz.org/gmsh/</u>.

After downloading it, open the program. Then you can open any STL file.

<u>F</u> ile	Tools	Window	Help	
New			Ctrl+	N
Oper	n		Ctrl+	0
Oper	n Recen	t		۲
Merg	e		Shift+Ctrl+	0
Wate	ch Patter	m		
Clea	r			
Rem	ote			۲
Rena	ame		Ctrl+	R
Save	e <u>A</u> s		Ctrl+	S
Save	Mesh		Shift+Ctrl+	S
Save	e Model (Options	Ctrl+,	J
Save	e Options	s As Defau	lt Shift+Ctrl+,	J
Quit			Ctrl+	Q
Op	ening S1	L file in the	GMSH UNV	
	con	verter softv	vare	

The geometry will be seen in GMSH.



Image 67: Geometry in the GMSH UNV converter software

The click on Save as and choose *.unv file format and rename the file to .unv.



Saving geometry in UNV file in GMSH UNV converter software.

After that, import the geometry in <u>Dewesoft X</u> in the same way as it is described on the previous page.

All the nodes and triangles are defined in the .unv file format.



Imported geometry that was converted in the GMSH UNV converter software

Geometry is now ready to be used for modal animation.



Geometry during the measurement

FRF - Frequency Response Function

For the following explanation of parameters, a triggered FRF was done on a snowboard structure. All 39 excitation points were sequentially hit by a modal hammer and relate to one reference response accelerometer.

Only 1 hammer and 1 sensor were used.

From the channel list on the right side, we see that each point (#1, #2, #3, #4) is related to the reference point (#1). For each excitation point, a transfer function was calculated, e.g. TF_1Z+/3Z+.



FRF functions consist of amplitude and phase information, or real and imaginary information, over a defined frequency range. The 2D graph is the graph widget to use for illustration. you can select what you want to display by using the properties from the left side.



Magnitude and phase of a frequency response function

To make a bode plot, use two 2D graphs below each other. The above one shows the amplitude (y-axis type: LOG), the lower one the phase (y-axis type: LIN).

When the amplitude of the transfer function shows a local maximum, and the phase has turned around 90 degrees at this point, it usually indicates a resonance. But to avoid an erroneous statement, other parameters have to be checked as well.



Determining modes from amplitude and phase information of an FRF.

Coherence

The coherence is used to check the correlation between output spectrum and input spectrum. Thereby, you can get indications of the power transfer between input and output of a linear system. Easily talking, it shows how good the input and output are related to each other.

The amplitude of the coherence goes from 0 to 1. Low values indicate a weak relation between input and output channels (e.g. due to noise or when the excitation spectrum has gaps at certain frequencies), and values close to 1 indicate good representative measurements.

NOTE: Coherence results must be based on averaged measurements. In the case no averaging is used the coherence will always show an incorrect value equal to 1.

If the transfer function shows a peak, but the coherence is low (orange circles in the picture below), it might not necessarily be a real resonance. Maybe the measurement has to be repeated (e.g. with a different hammer tip?), or you can additionally look for the MIF parameter, explained below.

Coherence is calculated over the frequency range and can be illustrated in a 2D graph widget.

Coherence channels are calculated separately for each point (e.g. Coherence_3Z/1Z, Coherence_4Z/1Z, …).



Coherence functions with valleys that indicate some frequency ranges where the related FRF functions will have a greater uncertainty.

The coherence function indicates the degree of a linear relationship between two signals as a function of frequency. It is defined by two autospectra (GAA, GBB) and a cross-spectrum (GAB) as:

$$\gamma^{2}(\mathbf{f}) = \frac{\left|\mathbf{G}_{AB}(\mathbf{f})\right|^{2}}{\mathbf{G}_{AA}(\mathbf{f}) \cdot \mathbf{G}_{BB}(\mathbf{f})}$$

For more information about autospectra and cross-spectra please look up:

- FFT Analysis Pro-training, Auto- and Cross-spectra
- FFT Analysis Ultimate guide, FFT Results

At each frequency, coherence can be taken as a correlation coefficient (squared) which expresses the degree of the linear relationship between two variables, where the magnitudes of autospectra correspond to variances of those two variables and the

magnitude of cross-spectrum corresponds to covariance.

There are four possible relationships between input A and output B:



Measurement screen - video

[Video available in the online version]

Mode indicator function (MIF)

If all parts of a structure are moving sinusoidally with the same frequency (fixed phase relations), this motion is called normal mode. This happens at resonance or natural frequencies. Depending on the structure, material, and bounding conditions there exist a number of mode shapes (e.g. twisting, bending, half-period, full-period movement...).

These are usually calculated using finite element simulation software, or/and by experimental modal measurement and analysis.

As mentioned earlier, when the amplitude of the transfer function shows a local maximum, and the phase is turning at this point, it usually indicates a resonance. To be sure, also the Coherence should be checked as described before. And last, you can look at the MIF (Mode Indicator Function).

In Dewesoft a MIF value close to 1 indicates a mode shape.

The spikes shown in the picture below are very likely resonance frequencies. Just click on them and check the movement in the geometry instrument.

The MIF function has values at all spectral lines should be displayed with a 2D graph widget.

The MIF is calculated from all FRF functions (all DOFs are included), and therefore the result is only one channel.





Note: in other SW applications the MIF is often shown by having valleys at resonances instead of peaks. In Dewesoft we use 1 - MIF compared to such other SW, in order to get modes indicated with peaks.

Structure movement animation

The structure movement animation is done by putting sine functions with the amplitudes and phases from the measurement into the geometry model points. The animation is done in one direction (in our example Z+). For FRF and Frequency ODS results you can animate the structure for a single frequency, which can be chosen in the 2D graph when setting the Cursor type to Channel cursor, as shown below.

Note that for Time ODS it is the time cursor in the Recorder widgets that will determine the time instance for the shown deflection shape.



Channel cursor applied to a selected frequency

Other than that, the frequency can also be chosen manually in the modal geometry widget properties on the left.



Animating the structure

Different parameters like animation speed and amplitude (scale), as well as the visibility (nodes, point numbers, traces, shapes, coordinate system axes), can be changed here.

Here are some of the mode shapes of the snowboard calculated by <u>Dewesoft X</u> Modal Test, where you can see bending and twisting/torsional modes.



Mode shapes at different frequencies

[Video available in the online version]
Modal circle

Finally, when you are certain that the point you are looking at is a resonance, you might want to get its exact frequency and damping factor.

As the FFT can never be that precise (high line resolution needs long calculation time, which is not given when there is a hammer impact), there are some mathematical methods to interpolate.



In the **Dewesoft Modal Test module**, the circle-fit principle method is included. The modal circle method can be used for simple SDOF structures having few, well separated, and lightly damped modes.

If more complex structures has to be investigated the **Dewesoft Modal Analysis module** should be used. The Dewesoft Modal Analysis module includes more advanced modal parameter estimation techniques capable of analyzing complex MDOF structures having many, closely couple, and heavily damped modes.

The Modal Analysis module features will be described later in this Pro-training material.

Circle fit analysis procedure

The FFT lines to the right and left side of a peak (so-called neighbor lines) are drawn by real and imaginary parts in the complex coordinate system. A circle is aligned between them with minimum error to each point and the resonance frequency is approximated.

The geometrical interpretation of the formula for the mobility FRF of damped SDOF system is a plot of Im(Y) vs. Re(Y). The picture below shows the mobility FRF of the damped SDOF system (Amplitude) and the Modal circle plot on the right side.



Circle fit analysis procedure

The selected point in the FRF curve should not be influenced by neighboring modes. The circle arc should be **around 270 degrees**.

The phase of the FRF curve should change for around 270 degrees. This is often not possible and a span of less than 180 degree is more usual.



Circle fit analysis in Dewesoft

The damping ratio is calculated using a user-defined number of points in the circle below and above resonance.



Imagine that we had a sample rate of 2000 Hz, and 1024 FFT lines, resulting in a line resolution of 0.977 Hz. The peak, that we are looking at, is at 73,2 Hz. But it could be in the range of 73,2 Hz $\hat{A} \pm 0,977 / 2$ Hz. In the example below, we switched the 2D graph's Graph Type property to histogram to make the FFT lines visible.

We add the Modal circle from the widget toolbar. The 2D graph is again in cursor mode, the modal circle widget will follow. By clicking on the peak, at first, no resonance peak is found.



Then we increase the Peak search range from 10 Hz to 20 Hz. The peak is found and by changing the neighbor count you can select how many FFT lines left and right from the peak are taken into calculation. The points should all be aligned nicely on a circle. The small red circle point shows the calculation result in the Modal circle widget.



A resonance frequency is found, by increasing the peak search range.

Our final result shows 72,775 Hz and a damping factor of 0,038. With these parameters, one can proceed further in the Dewesoft Modal Analysis module or in other simulation software.

[Video available in the online version]

Modal Analysis of complex structures

As mentioned in the beginning of this training material, the **Dewesoft Modal Test** module is what you use when acquiring structural dynamic test data of objects, which provide calculated FRF and other modal related function types. The **Dewesoft Modal Analysis** module is used in Analyze mode, after the modal test data acquisition, in order to estimate high quality modal models.

Where Dewesoft Modal Test mainly provide tools to determine modal parameters of simple structures, having lightly damped and well separated modes, Dewesoft Modal Analysis provide tools to determine valid modal parameters for complex structures, having multiple resonance frequencies being closely spaced and with heavy damping.



Example of a display configuration for Modal Analysis in Analyze mode.

The Dewesoft Modal test module is included in the Dewesoft X DSA package (along with other modules e.g. Order tracking, Torsional vibration, etc.).

The Dewesoft Modal Analysis module comes as a separate license and is not included in the DSA package.

Why estimate a modal model?

Why use the Modal Analysis module to estimate modal parameters instead of just using the parameter values found with the tools from the Modal Test module? This depends on the test structure, if it's structural dynamic behaviors are relatively "simple" or more "complex".

SDOF curve fitting (supported in the Modal Test module) can be used on simple structures with well-separated modes having only small mode overlaps, or at certain frequency bands where the structure fulfills such requirements. At resonance frequencies simple structures will behave like a SDOF system. For SDOF systems the Modal Circle widget can be used to indicate acceptable resonance and damping values.

When structures are lightly damped (<1 % damping) this often causes the present modes to have small overlaps - the modes are said to be lightly coupled.

MDOF (Multi Degree Of Freedom) Fitting

MDOF curve fitting (supported in the Modal Analysis module) should be used on complex structures with closely spaced modes and with heavily damped modes which cause overlaps between modes. MDOF curve fitting can be used at certain frequency ranges where such characteristics occur or over the full frequency range.

MDOF fitting is done by estimating a modal model, which can separate all modes (also overlapping modes) from each other and hereby determine valid modal parameters even though the modes are closely couple. This is not possible for the SDOF fitting methods.



Sketch of an FRF curve and three-mode fittings. The first mode fit is well separated from the other modes and an SDOF fit can be used in this frequency band. Mode fit 2 and 3 are closely spaced and an MDOF fit should be used in this frequency band.

Modal parameter estimation

Modal parameter estimation becomes relevant when measured FRFs contain overlapping modes. If modal parameters for complex structures are estimated as being SDOF systems (by using e.g. the Modal Circle fit method and quadrature picking), then other modes close by will affect the mode estimation and results will be inaccurate.

In order to estimate modes of complex structures without getting affected by other closely coupled modes, MDOF curve fitting is used where a series of SDOF systems are optimized to fit/mimic the CMIF best possible. The number of SDOF systems in the final estimated model is based on the number of poles (and hereby modes) selected on the Stabilization diagram.

By being able to describe measured FRFs (that have a mix of overlapping modes) with a series of SDOF systems, it becomes possible to accurately estimate each mode without they are being affected by other nearby modes.

One of the main parameters used in curve fitting is the Order, also referred to as Iterations or Modal Size, which defines the polynomial order of the fitted mathematical function. Order needs to be set high enough to be able to fit the function to all modes included in the selected frequency range/band, and also high enough to compensate for the residual effects of modes that lie outside of the selected curve fitting band.

But if the fitting order is set too high, the fitting function will begin to fit noise in addition to the modes and will represent nonphysical Computational Modes as well.

DewesoftX Modal Analysis setup

In order to get started with DewesoftX Modal Analysis, add the Modal analysis module like shown below:

More Remove		
modal	Add module Analysis defaults	
Modal analysis		
Modal test	*	
(()) Time ODS		

Adding Modal Analysis to the current setup.

Note that modal analysis output channels will only be calculated after measurements has been acquired, using the related datafiles in Analyze mode.

The modal analysis setup has a table containing added FRF functions to the left and General settings on the right side.



Modal Analysis setup.

Transfer functions table

In the Transfer functions table you must add the measured FRFs you want to use from Modal Test. This can be done either by pressing Add all TFs, which will import all measured FRFs in the datafile, or by pressing Add, which will add one row to the table for you to assign an FRF to.

The Transfer function preview tab will show the FRFs that are set to **Preview** - > **Enabled** (>>) which can help with determining the relevant frequency range to include for the estimation proces. The Preview will also illustrate which modes are present between all FRFs (global modes) and which are only found at one or few FRFs (local modes).

When performing global mode curve fitting all FRFs should contain the global modes. Otherwise, the global estimation might be inaccurate.

General settings

Under General settings you start with selecting the **frequency range** for the analysis. Maybe the full range must be analyzed or maybe only a certain frequency region is of interest.

The **Damping correction** parameter should be enabled if you have used the Force + Exponential FFT window for the measured FRFs.

General settings			
	Entire range	Damping co	prrection
Lowest frequency	0,00 Hz		
Highest frequency	250,00 Hz		
Transfer function p	oreview Transfer	function matrix Cal	culations
Stabilization			
Offline	✓ Max order	Frequency	tolerance Damping tolerance
	70	0,010	Hz 0,100
Outputs			
Туре	Used		
CMIF	Offline		
FRF synthesis	Offline		
Mode shapes	Offline		
AutoMAC	Offline		

General settings for Modal Analysis setup.

Calculations tab

Under the Calculation tab you can adjust settings for the Stabilization Diagram, and which output functions you want to include. We will get back to the Stabilization diagram in the next section.

- Max order Increasing the order of the curve fit will also increase the number of calculated poles to select between in the Stabilization diagram. When the calculated poles begin to only change a little between individual neighbor orders, then the poles are said to be stable.
- Frequency tolerance Defines the limit for how much neighboring poles must deviate in frequency in order to be Frequency

stable poles.

• **Damping tolerance** - Defines the limit for how much neighboring poles must deviate in damping to be stable poles with respect to damping.

The **Outputs** section determines which output functions that will be calculated. **Offline** means that the function is calculated in Analyze mode - like we do when using the Modal Analysis module. The function type will not be calculated if it is set to **Unused**.

- CMIF Complex Mode Indicator Functions (CMIF), have one function for each reference DOF included (poly reference) and can help identifying closely coupled modes and repeated roots. CMIF is based on Singular Value Decomposition (SVD) of all the Used FRF functions, to identify all modes included in the model test measurements. The CMIF functions have peaks at resonances indicating poles of the DUT.
- FRF synthesis FRF Synthesis is used as a validation tool by comparing the FRFs from the estimated modal model (the synthesized FRFs) with the real measured FRF data.
- Mode shapes Outputs the mode shapes for the modes selected on the stabilization diagram based on the estimated modal parameters.
- AutoMAC The Modal Assurance Criterion (MAC) is used to determine the similarity of two mode shapes. "Auto" in AutoMAC means that the two mode shapes comes from the same test.

Stability Diagram

You use the Stabilization Diagram (or SD) to determine what the modal parameter identification should be based on. It helps with identifying stable poles and thereby consistent modes which can be used for the modal parameter estimation process. The poles consist of the modal frequency and damping. When the poles are green circles it fulfills the tolerance settings for stable frequency and damping, as specified under General settings in the Modal Analysis setup.



Stability diagram widget, with poles (green and gray) for modal curve fits and CMIF data (red and orange)

You must select a stable pole from each mode you want to estimate, by left-mouse-clicking on the poles. When the set of poles are selected press the **Recalculate** button and estimation process will be done, as shown below:



On the stabilization diagram you can also display the CMIF curve(s) which help with overviewing the detected structural modes when you are selecting poles for the estimation process. CMIF is based on Singular Value Decomposition (SVD) of all the Used FRF functions to identify all modes included in the model test measurements. The CMIF functions have peaks at resonances indicating poles of the DUT.

CMIF outputs one function for each reference DOF included.

The stabilization diagram can be added to the Analyze - Review display by adding the widget as shown below:



Adding a Stabilization diagram to the Review display.

Modal model validation

When stable poles have been selected on the stabilization diagram and modal parameters have been calculated, you should validate that the quality of the results by using **Modal Assurance Criteria** (MAC) and by comparing the **synthesized FRFs** with the measured FRFs. If both MAC results and the synthesized FRFs looks good, then you have obtained representative resonance frequencies, damping ratios and mode shapes for the individual modes of the structure - even though some modes are closely coupled.

AutoMAC

AutoMAC is used to verify that the selected and estimated modes can be distinguishable with the amount of FRFs used. If too few DOFs are measured two different modes might behave in the same way at the DOF nodes being measured. In such cases multiple modes are not distinguishable and the modal estimation might mix mode information together.

To ensure an acceptable spatial resolution, enough DOFs must be used to detect unique mode characteristics for all modes. Also, the DOF node positions have to be chosen in ways that detects all those modes and their differences between each other.

The AutoMAC results has a value between 0 and 1 for all mode pairs. A value of 1 means that the pair of modes are 100 % correlated, and a value of 0 means that the mode pair do not have anything in common. In the picture below you see an AutoMAC of a modal model with 9 modes. The diagonal mode pairs (mode 1:1, 2:2, ... 9:9) will always have a value of 1 since the modes will always be 100 % correlated with itself. On the other hand, off-diagonal values (e.g. mode 1:2 and 3:5) should be as low as possible to indicate that the estimated modal is based on data with distinguishable modes.



AutoMAC displayed with a 3D graph widget.

Synthesized FRFs

FRF synthesis is a validation tool used by comparing the FRFs from the estimated modal model (the synthesized FRFs) with the real measured FRF data. It is therefore possible to see how well the estimated model mimics the dynamics of the physical structure. If the synthesized FRFs looks similar to the measured FRFs it verifies that the modes of the measured structure can be described by the estimated model - This means that it has been possible to describe the structure successfully with a series of SDOF systems, which have well defined modal parameters.



Measured (red) and synthesized (blue) FRF comparison. In this example the modal model is very nicely describing the measured structural dynamics.

Mode shapes

The mode shapes are estimated by an LSFD (Least-Squares Frequency Domain) method. The LSFD performs local estimates based on individual FRF measurements together with the Global modal parameters (frequency and damping), which were estimated by the MDOF global curve fitter.

The mode shapes for each mode are vectors consisting of complex values for each DOF point. The complex values describe how the DOFs are moving relative to each other for a certain mode. In the illustration below estimated mode shapes of a complex structure is animated. For each estimated mode a mode shape vector is determined and used for animation.



Animation of estimated mode shapes.

Mode shape animation can help you with verifying the how the estimated modal describe the measured FRF data and FEM models by comparing the animations of measured or analytical FRFs with the estimated mode shapes.

Export of complex data

After the measurement is done the data can be exported to a lot of different file formats, e.g. UNV/UFF, Diadem, Matlab, Excel, Text... The modal data results can be separately exported by Real, Imag, Ampl or Phase parts, whatever you prefer.

[Video available in the online version]

Export type	Channels							
Excel (*.xlsx) ~	Search	٩		$\Theta \Theta$				
Data presentation	Export order	Export order	Ex	Ch. no	Name	Sampling	Rate	Dat ^
Full speed data V Absolute time V	1	1	No	MT (Modal test)	Coherence_20Z+/1Z+	Single value	unknown	Vec
	2	2	Yes	MT (Modal test)	TF_20Z+/1Z+	Single value	unknown	Vec
Settings	3	3	No	MT (Modal test)	Coherence_20Z+/2Z+	Single value	unknown	Vec
Export setup to xml file	4	4	Yes	MT (Modal test)	TF_20Z+/2Z+	Single value	unknown	Vec
Ignore gaps between triggers	5	5	No	MT (Modal test)	Coherence_20Z+/3Z+	Single value	unknown	Vec
Export per channel	6	6	Yes	MT (Modal test)	TF_20Z+/3Z+	Single value	unknown	Vec
Export async channels to highest rate	7	7	No	MT (Modal test)	Coherence_20Z+/4Z+	Single value	unknown	Vec
Append type to channel name	8	8	Yes	MT (Modal test)	TF_20Z+/4Z+	Single value	unknown	Vec
Export file name	9	9	No	MT (Modal test)	Coherence_20Z+/5Z+	Single value	unknown	Vec
	10	10	No	MT (Modal test)	TF_20Z+/5Z+	Single value	unknown	Vec

Exporting complex channels

In MS Excel, for example, FRF data will appear on a sheet called Single value. For each FRF, Real/Imag/Ampl/Phase is exported.

If you prefer it differently, data rows and columns can simply be exchanged in MS Excel by copying and using the Transpose function from the submenu when pasting.

	1	4	В	С	D	E	F	G	Н
1	Frequenc	y	Hz	0	2,441	4,883	7,324	9,766	12,207
2	TF_1Z+/12	Z+_Real	g/N	-2,4849606	-0,58888257	-0,33757547	-0,18308581	0,01226047	-0,04376284
3	TF_1Z+/12	Z+_Imag	g/N	-0,38368255	0,97344095	-0,10276848	-0,19029871	0,03687299	0,00500704
4	TF_1Z+/12	Z+_Ampl	g/N	2,5144067	1,1377038	0,35287187	0,26407197	0,0388579	0,04404834
5	TF_1Z+/12	Z+ Phase	Rad	-2,9884005	2,1148472	-2,8460755	-2,3368793	1,2497911	3,0276749
6								1	
7	Frequenc	Y	TF_1Z+/1Z+_Real	TF_1Z+/1Z+_Imag	TF_1Z+/1Z+_Ampl	TF_1Z+/1Z+_Phase			
8	Hz		g/N	g/N	g/N	Rad			
9		0	-2,4849606	-0,38368255	2,5144067	-2,9884005			
10		2,441	-0,58888257	0,97344095	1,1377038	2,1148472			
11		4,883	-0,33757547	-0,10276848	0,35287187	-2,8460755			
12	×.	Ausschne	iden	-0,19029871	0,26407197	-2,3368793			
13	Po Po	Konjeren	lach	0,036872987	0,038857896	1,2497911			
14	43	Cieffieren		0,005007039	0,044048339	3,0276749			
15		Einiugeoj		-0,000328444	0,015436211	-3,1203136			
16		123	fx 🚰 🍫 🥃	0,007050768	0,025219958	2,8582454			
17		Inhalte ei	nf <u>üg</u> en k	0,009580854	0,034467768	2,8599172			
18		Zellen ein	fügen	0,021826826	0,047330786	2,6622963			
			199 - - 9994.						
28]	46,387	0,014677704	0,21595292	0,21645114	1,5029335			
29		48,828	0,12720668	0,23750821	0,26942846	1,0790849			
30	-	51,27	0,21473587	0,17970231	0,28000787	0,69681174			
31		53,711	0,23269501	0,12583467	0,26453987	0,49572986			
14 4	+ H Si	ngle value	Data1 / Events	/ DataInfo / 🐑 /			Ī	4	

Export of complex data to MS Excel

Export to UNV / UFF format

The Universal File Format (also known as UFF or UNV format) is very common in modal analysis. Depending on the header, it can contain either transfer functions, coherence, geometry, ... or various other data.

The following example shows how to export data recorded by <u>Dewesoft</u> into Vibrant Technologies ME Scope analysis software and how to display it there.

First, choose the UNV export from the export section and the option Export complex channels if you want to export phase, real and imaginary part. Then select all your transfer functions (you can use the Filter and type TF for simplification). When clicking on the Export button you will create a UNV datafile.

Dewesoft X - Datafile					Simulation mod	le	- 0	\times
Measure Analyse Data files Setup Review Print Export							≡ c	Options
Dewesoft File export Flexpro MS Excel Clipboard Export								
Export type	Channels							
UNV Export (*.unv) V	tf	8	\otimes \otimes					
Data presentation	Export order	Ex 🔳	Ch. no	Name	Sampling	Rate	Data str 🔳	^
Full speed data V Absolute time V	2	Yes	MT (Modal test)	TF_20Z+/1Z+	Single value	unknown	Vector (1024)	Co
Real Imag Ampl Phase	4	Yes	MT (Modal test)	TF_20Z+/2Z+	Single value	unknown	Vector (1024)	Co
Settings	6	Yes	MT (Modal test)	TF_20Z+/3Z+	Single value	unknown	Vector (1024)	Co
Export setup to xml file	8	Yes	MT (Modal test)	TF_20Z+/4Z+	Single value	unknown	Vector (1024)	Co
Ignore gaps between triggers	10	Yes	MT (Modal test)	TF_20Z+/5Z+	Single value	unknown	Vector (1024)	Co
Export per channel	12	Yes	MT (Modal test)	TF_20Z+/6Z+	Single value	unknown	Vector (1024)	Со
Export header	14	Yes	MT (Modal test)	TF_20Z+/7Z+	Single value	unknown	Vector (1024)	Co
Universal file format 58b	16	Yes	MT (Modal test)	TF_20Z+/8Z+	Single value	unknown	Vector (1024)	Co
Export complex channels [e.g. Modal test]	18	Yes	MT (Modal test)	TF_20Z+/9Z+	Single value	unknown	Vector (1024)	Co
Export "Dataset" Nowhere 🗸	20	Yes	MT (Modal test)	TF_20Z+/10Z+	Single value	unknown	Vector (1024)	Co
Export "Start Time" Nowhere	22	Yes	MT (Modal test)	TF_20Z+/11Z+	Single value	unknown	Vector (1024)	Co
Export "ChannelName" Nowhere V	24	Yes	MT (Modal test)	TF_20Z+/12Z+	Single value	unknown	Vector (1024)	Co
	26	Yes	MT (Modal test)	TF_20Z+/13Z+	Single value	unknown	Vector (1024)	Co
	28	Yes	MT (Modal test)	TF_20Z+/14Z+	Single value	unknown	Vector (1024)	Co
O.unv ●.uff	30	Yes	MT (Modal test)	TF_20Z+/15Z+	Single value	unknown	Vector (1024)	Co

Exporting to UNV file format.

In the Geometry editor the structure can also be exported separately to the UNV format. This creates the UNV geometry file.

1	🖸 UI	NV Edit	or						-	-
ľ	iie (Clear st	ructure	Q	uads					
4	L	.oad UI	٧V		z	X angle	Y angle	Z angle		
С	S	ave UN	۱V							
F	E	xit		0	0	0	0	0		
	P	oints	x	Y	z					
	1	1	0,2	1	0,4	16	0	0		
r	2	2	-0,2	2	0,1	8	0	0		
	3	3	0	3	0	0	0	0		
	4	4	0	4	0	0	0	0		
	5	5	0	5	0	0	0	0	1 z	
	6	6	0	6	0	0	0	0		
	7	7	0	7	0	0	0	0		
	8	8	0	8	0	0	0	0		
	9	9	0	9	0	0	0	0		
	10	10	0	10	0	0	0	0	× 30 31 32 33 21 23 30 10 44 10	
	11	11	0	11	0	0	0	0	34 35 22 24 25 26 34 35 36 36 24 35 26 3 36 36 36 36 36 36 36 36 36 36 36 36	
	12	12	-0,2	12	0,1	-8	0	0		Y
3	13	13	0.2	13	0.4	-16	0	0		

Export geometry as an UNV file.

UNV files can be imported to a software application supporting UNV files (like ME Scope, N-Modal, ...). In ME Scope click File -> Import -> Data block. Then select the UNV datafile.



Import data block in ME Scope.

The transfer functions are now illustrated.



Imported transfer functions in ME Scope.

2. Then click File -> Import -> Structure and select the UNV geometry file.



Import the structure to ME Scope.

Now both data and geometry are successfully imported into ME Scope. Let's try to animate it, select Draw -> Animate Shapes.

ME'scopeVES (64 bit): New Project 2.V	Лргј	the improvement of the	
Project Window File Edit Display	raw Animate Movie SDM FEA	Program MechaniCom Help 🔓	📲 🔳 🔳 📑 당 당 🖻 🗎
i d 🖨 🖬 🔲 🚽 🖉 🖬 🗖	Draw Structure	» 🛊 - 🛶 🔤 🕼 - 🛛 🐐	🖥 🦯 🗯 💁 🛆 🛦 💧 🛛 BLK: FRF_r
Project Demos Application Notes	Angate Shapes		
	Compare Shapes	9	
	Drawing Assistant		
STR: metal_beam - 3D View	Points +		
View: 3D View	Resize Selected Objects	Select	Visible Label Color Bold Trans
	Drag Selected Objects	SubStructure	
G	Rotate Selected Objects		
	Mesh Objects		
	SubStructure +		
	Animation Equations		
	0		
	9		
		7	
		X	
		<u>∎</u> ∎ ш	

4.

Animating the structure in ME Scope.

A pop up appears, and we select to match the structure and transfer data. Equations are created.



Finally, you can select a peak on a transfer function and enjoy the animation.



Animation of a structure at a selected peak in ME Scope.

Example - Imapct hammer measurement

In order to get a better understanding of modal measurement procedures, this section shows how to use the mentioned modal test controls and tools step-by-step.

As an example, let's say we want to analyze this metal sheet structure in the picture below. At first, we define the direction of analysis (orientation up/down, Z-axis), then we put it on a soft rubber foam such that it can vibrate freely. Alternatively the plate could be hanging in rubber bands to achieve more free structural vibrations, but for this example the foam is ok.

Now, mark node points on the structure, in our case from #1 to #24. With increasing number of DOF points, the spatial resolution becomes better. With insufficient DOFs used there will not be enough information to describe and animate all modes separately.

It is also helpful to write numbers (Node IDs) next to the points. They should be consistent with the structure, channel setup, and Modal geometry in software.



Impact hammer modal measurement on a metal plate

In this example we use a roving modal hammer and one reference response accelerometer to perform a SISO modal test. The hammer will make a series of impacts at all nodes while the accelerometer will be mounted at a fixed location.

We define the sampling rate as 5000 Hz. Name the hammer and accelerometer in the channel setup and apply correct sensor scaling. In our case, both the hammer and accelerometer are IEPE sensor types with TEDS, so the sensor data including scaling is automatically handled by Dewesoft. The hammer is measuring the force in N and the accelerometer measures the acceleration in g.

To manually configure the sensors go to Channel setup and enter the Setup.

l	Device	preview			Dynamic acquisit	ion rate Ch	anne	el actions									
	SOUL: The S	ಁೢಁೢ	Ó	? <i>``</i> ?` <i>`</i> ?`	5000 (Hz)	Bandwidth: 1953 Hz		Balance amplifiers	Short on	Zero all	Reset ze	ero all					
	Search		_	Q													
	ID	Used	C.	Sample	Name	Ampl. name		Range 📃	Measurer	nent 🔳	Min	Values	Max	Physical quantity	Units	Zero 🔳	Setup
	1	Used		5000	Modal hammer	SIRIUS-ACC+	+ 10000 mV		IEP	E	-904,83	0,00	904,83	Force	N		Setup
	2	Used		5000	Accelerometer	SIRIUS-ACC+		10000 mV	IEP	Έ	-978,22	0,00	978,22	Acceleration	m/s2		Setup

Channel setup for the measurement example.

In Modal Test setup (MT) choose the Impact hammer Test method and check on Roving hammer/response. Make some test impacts and set the trigger level somewhere below the max value of these impact levels. We will do 4 hits at each point, which are then averaged. The FFT number of lines is set to 1000 giving a window length of 0.4s, and a line resolution of 2.5 Hz.



Now that the excitation and response points are defined, go to the Geometry tab under Modal Test to create the plate geometry. In this example the plate can easily be created by entering the Object Editor under the Objects tab. Here, a plate object can be defined with the right size and number of nodes.



Creating the geometry of the plate.

Now it's time for some test hits to get familiar with the setup. Go to Measure mode, without storing, and select the pre-defined display template for MT - Impact Hammer. When you do a test hit that exceeds the trigger level then data will be displayed in the graph widget.

From the time the first DOFs are measured the structure will begin to be animated.



Image 110: Pre-defined display for impact hammer measurement

To be sure that the FFT block length covers the entire impact and related output response you can look at the scope displays in the upper right corner of the displa template. If not the full impact energy is covered the FFT block duration should be increased (use a higher line resolution or lower sampling rate).

Now we are ready for the measurement. Start storing and do 4 hits on point #1. The scope and FFT graphs will be updated after each hit, so you can visually check for double-hits or bad hits and reject them. If you hit the wrong point, you can also reset the whole point. After clicking the Next point button, the point number increases, always showing you the current transfer function.

The procedure can also be described by a flow chart:



Modal test measurement procedure

When finished, go to Analyse mode. Automatically the last stored file is reloaded. Now you might want to modify the screen for further investigation. The screen below gives an idea. It shows the first four transfer functions (TF12-1, 12-2, 12-3, 12-4) with amplitude and phase. Below the MIF is shown for easily finding the modes. Just click on the peaks (with the widget set to Channel cursor mode), on the lower right side, the modal circle calculates the exact frequency and damping.



Modal test results in Analyse mode

Here are some of the mode shapes animated.



1.

[Video available in the online version]

Example - Shaker measurement

This is a practical example showing the Shaker Test method. The Analog out of a <u>SIRIUS</u> DAQ instrument (Dewesoft AO) is connected to an audio amplifier which drives a loudspeaker. On the membrane, a metal structure (metal beam) is mounted on a force transducer (excitation) and two acceleration sensors (responses).



signal.

In the Analog in Setup section tab, we define our force sensor and the three accelerometers. They are all of IEPE type. As we want to analyze our structure up to 1000 Hz, we select a sampling rate of e.g. 5000 Hz.

O Store	E Save	Save as	Stor	ring Analog in	+÷ πΣ Math	мт	More	Remove	
Dynamic	c acquisition	rate	Chan	nel actions					
5	~	Bandwidth: 1953 Hz		Balance amplifiers	Short on	Zero all	Reset ze	ro all	
(kHz)	•								
Search		٩							
ID	Used	Stored	С.	Sample rate	Name		Ampl. name 🔳		
1	Used	Store		5000	Force	DE	DEMO-SIRIUS-AC		
2	Used	Store		5000	Acc 1	DE	MO-SIRIUS-	AC	
3	Used	Store		5000	Acc 2	D	EMO-SIRIUS	-CHG	
4	Used	Store		5000	Acc 3	DE	DEMO-SIRIUS-STG		

Analog in section tab for setting up the sensors.

Next, we add a Modal test module and select the Shaker Test method. The FFT window size gives 1000 spectral lines which results in a resolution of 2.5 Hz. We select Dewesoft AO as Excitation source, and choose the Sine sweep Waveform. The sinusoid is set to sweep logarithmic from 10 Hz to 1000 Hz. The Node IDs are entered according to the structure, the direction is Z+ for all.

		Excitati	on Resp	onse Tran	sfer functions	Geometry edi	tor						
Measurement		Excitatio	n settings										
Test method		Excitatio	on source	Wave	Waveform		q.	Stop freq.	_	Sweep type		Sweep time	~
Shaker ~		Dewesoft AO V Sine sweep V 10 Hz 1000 Hz Logarit						Logarithn	nic 🗸 6	i0	S		
Roving response		AO soft	start/stop	c	Continuous exe	citation settings							
FRF		Start tim	art time Stop time FFT window Signal overlap										
Resolution		0,5	s 0,5	s	Hanning	~ 66,7		~ %					
Spectral lines ~ 1000													
lines: 1000, df: 2,5 Hz, duration: 0	,4s	Excitatio	n channels										
Averaging type		\odot	- Ai	utofill	Search	٩	🗹 Sh	ow message if	excitatio	on exceeds	; 20	Ν	
Linear ~		Node I	D Directi	ion Sign		Input	Physica	al quantity	Units	A	0 channel	AO	amplitude
Stop after		1	7	+		Force	F	orce	N		AO 1		1.00 V
4 avg.		-	-										2,000
Output channels				1 -				_					
Output	Used		Excitation	Response	Transfer f	functions Geom	netry editor	•					
H1 transfer functions	Lised		C C	nanneis									
	- Obcu		\oplus \ominus	Autofil	Sea	arch	Q						
H2 transfer functions *	Unused		Node ID	Direction	Sign	Input		Physical guar	ntity	Units			
Ordinary coherence		1	7	-	Acc. 1		Acceleratio		m/s7				
Multiple coherence *		-	-	T	ACC 1		Acceleratio		11/32				
Power spectral density		2	Z	+	Acc 2		Acceleration		m/s2				
Ordinary mode indicator function	Used		3	Z	+	Acc 3		Acceleratio	on	m/s2			
Intermediate Fourier transforms	Unused												

Modal test channel setup for the shaker measurement example.

Now lets draw i simple geometry by enterring the Geometry editor tab under the Modal Test setup module.

E	xcita	ition	Response	Trans	fer functior	ns Geom	etry edito				
G	ome	try edit	or								
	ile	Tools									
0	bjec	ts No	odes Li	nes Su	rfaces						Z
(Image: Show unused points Add Cartesian CS Add Cylindrical CS										Y
+	I.	No	х	Y	Z	X angle	Y angle	Z angle	Object	State	X X
4		Ca	0,00	0,00	0,00	0	0	0			↑z x
	0	1	1,00	0,00	0,00	0	0	0	-1	Measured	2
	1	2	2,00	0,00	0,00	0	0	0	-1	Measured	
	2	3	3,00	0,00	0,00	0	0	0	-1	Measured	
											🖄 🎦 🕺 🖉 🔪 Left dick: select node. Right dick on node: open context menu.

Creating the geometry for the shaker test example.

Now we are ready to measure. When you click the store button, the function generator will start, the AO will sweep from 10 to 1000 Hz. The transfer functions will smoothen from left to right side, here you see a snapshot currently at 357 Hz.



Measurement screen during the shaker measurement

Finally, we can look at the result. The coherence related to the excitation looks very nice. The green line (MIF) indicates mode shapes, click on the peaks and the structure will be animated.



Review of measurement results in Analyse mode